

# Sample gas cooler

# Series TC-Standard X2

# Installation and Operation Instructions

**Original instructions** 





Bühler Technologies GmbH, Harkortstr. 29, D-40880 Ratingen Tel. +49 (0) 21 02 / 49 89-0, Fax: +49 (0) 21 02 / 49 89-20 Internet: www.buehler-technologies.com E-Mail: analyse@buehler-technologies.com

Read this instruction carefully prior to installation and/or use. Pay attention particularly to all advises and safety instructions to prevent injuries. Bühler Technologies can not be held responsible for misusing the product or unreliable function due to unauthorised modifications.

All rights reserved. Bühler Technologies GmbH 2025

Document information Document No.....BE440023 Version.....10/2024

## Contents

1	Intro	oduction	
	1.1	Intended use	
	1.2	Overview	4
	1.3	Type plate	4
	1.4	Scope of delivery	4
	1.5	Ordering instructions	5
		1.5.1 Gas cooler models with one heat exchanger	
		1.5.2 Gas cooler models with one heat exchanger for H2/O2 applications	
		1.5.3 Gas cooler models with two heat exchangers	
		1.5.4 Gas cooler model with two heat exchangers in series	8
2	Safe	ty instructions	9
	2.1	Important notices	
	2.2	General hazard warnings	
-			
3	Iran	sport and storage	. 12
4	Insta	allation and connection	. 13
	4.1	Installation site requirements	. 13
	4.2	Installation	. 13
		4.2.1 Connecting the filter gas connections (optional)	. 14
		4.2.2 Flow adapter connection (optional)	. 14
		4.2.3 Connecting the moisture detector (option)	
		4.2.4 Peristaltic pump connector (optional)	. 14
		4.2.5 Connecting the heat exchanger	
		4.2.6 Condensate drain connection	
	4.3	Electrical connections	
	4.4	Signal outputs	17
5	Onei	ration and control	19
5	5.1	Description of functions	
	5.2	Delta T control option	
	5.3	Use of menu functions	
	5.5	5.3.1 Lock Menu	
		5.3.2 Menu navigation overview	
	5.4	Description of menu functions	
	5.1	5.4.1 Display menu	
		5.4.2 Main menu	
		5.4.3 Submenu 1	
		5.4.4 Submenu 1 (global settings)	
		5.4.5 Set favourite menu	
~			20
6	Mair	ntenance	. 29
7	Servi	ice and repair	30
	7.1	Troubleshooting	30
		7.1.1 Error messages on the display	. 31
	7.2	Safety instructions	. 32
	7.3	Cleaning and removal of the heat exchanger	. 33
	7.4	Replacing the hoses of the peristaltic pump (option)	. 33
	7.5	Replacing the filter element (option)	. 33
	7.6	Drying of the moisture detector (option)	. 34
	7.7	Calibration of the moisture detector (option)	
	7.8	Replacing the base unit	
	7.9	Spare Parts	
		7.9.1 Consumables and accessories	
		7.9.2 Spare parts and accessories for cooler with -H2/-O2 heat exchanger	
8	Dicn	osal	36
	-		
9	Арре	endices	. 37

	9.1	Gas cooler technical data	37
	9.2	Technical Data - Options	40
		Flow diagrams	
	9.4	Performance curves	42
		Heat exchanger	
		9.5.1 Heat exchanger description	44
		9.5.2 Heat exchanger overview	44
	9.6	Dimensions (mm)	46
10	Attac	ched documents	49

## 1 Introduction

## 1.1 Intended use

This unit is intended for industrial use in gas analysis systems. It's an essential component for conditioning the sample gas to protect the analysis instrument from residual moisture in the sample gas.

Sample gas coolers with the option for high-purity oxygen (suffix -O2) are optimised especially for use with increased oxygen concentrations with regard to the parts in contact with the medium. Special cleaning of the components to minimise organic and inorganic contamination is mandatory. Manufacturing the products under controlled cleanliness conditions ensures compliance with the limit values in accordance with EIGA Doc 33/18.

Sample gas coolers with the option for high-purity hydrogen (suffix -H2) are specially refined using advanced manufacturing measures, in particular to prevent hydrogen-induced component damage. In addition, the parts in contact with the media are subjected to an additional visual inspection to remove any residual metallic contamination, such as chips and particles. Finally, a leak test is carried out as standard.

The device must not be operated in a zone 2, explosion class IIC (ATEX, IECEx and EAC Ex) explosive gas atmosphere which is rarely and only temporarily explosive, and in class I, division 2 (US & Canada).

For passing of flammable gases, make sure that the parts carrying and/or in contact with the medium are tightly connected.

Optional installation of various add-on equipment may limit the area of application of this device.

#### **Coolers with Canada certificate and IECEx**

The device must be installed in a tool-secured IP54 housing.

#### **Coolers with USA certificate**

The device must be installed in a tool-secured IP54 housing suitable for one or more class I division 2 wiring methods according to National Electric Code (ANSI/NFPA 70).

#### **Coolers with ATEX certificate**

The device must be installed within a tool-secured enclosure providing a minimum degree of protection of IP54 and meeting the requirements of EN 60079-0 or certified as Ex e and in compliance with the enclosure, mounting, spacing and segregation requirements of the ultimate application.

#### **Coolers with EAC Ex certificate**

The device must be installed in an IP54 rated housing which meets the requirements of GOST 14254-2015.

Please note the specifications in the data sheet on the specific intended use, existing material combinations, as well as pressure and temperature limits.

### **1.2 Overview**

The TC-Standard X2 series was designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 series was designed specifically for the requirements in so-called automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimise wash-out effects.

The TC-Standard X2 with -H2/-O2 heat exchanger series was specially developed for use with high-purity hydrogen and oxygen.

The Peltier coolers are distinguished according to cooling capacity / operating temperature. This classification is reflected in the type designation. The exact item number of the model defined by you is determined by the model code in the ordering information category.

Application	Standard ar	oplications
Operating temperature	40 °C	50 °C
1 heat exchanger	TC-Standard 6111 X2	TC-Standard 6112 X2
1 heat exchanger for $-H_2/-O_2$ applications	TC-Standard 6111 X2	TC-Standard 6112 X2
2 heat exchangers	TC-Standard 6121 X2	TC-Standard 6122 X2
2 heat exchangers in series	TC-Standard+ 6121 X2	TC-Standard+ 6122 X2


Additional components which every conditioning system should feature can optionally be integrated:

- Peristaltic pump for condensate separation,
- Filter,
- Moisture detector.

This allows for various configurations of cooler and options. Here the approach is to simplify creating a complete system in a cost-efficient way through pre-installed components with hoses connected. We further paid attention to easy access to wear parts and consumables.

## 1.3 Type plate

#### **Example:**



## 1.4 Scope of delivery

- Cooler
- Product documentation
- Connection-/mounting accessories (optional)

## **1.5 Ordering instructions**

## 1.5.1 Gas cooler models with one heat exchanger

The item number is a code for the configuration of your unit. Please use the following model code:

4496	2	1	1	х	2	x	1	х	х	х	0	х	х	х	0	x	0	0	Product Characteristics

												Gas cooler models (with 1 heat exchanger)
1												TC-Standard 6111 X2: Ambient temperature 40 °C
2												TC-Standard 6112 X2: Ambient temperature 50 °C
												Certifications
	2											for explosive areas
												Supply voltage
		1										115 V AC, 50/60 Hz
		2										230 V AC, 50/60 Hz
		4										24 V DC
												Heat exchanger
			1 1	(	0							Stainless steel, PTS, metric
			1 1	1	5							Stainless steel, PTS-I, US
			1 2	2 (	0							Duran glass, PTG, metric
			1 2	2 !	5							Duran glass, PTG-I, US
			1 3	3 (	0							PVDF, PTV, metric
			1 3	3 !	5							PVDF, PTV-I, US
												Condensate drain <sup>1)</sup>
					C	0	)					without condensate drain
					1	0	)					CPsingle X2 with hose nipple, angled
					3	3 0	)					CPsingle X2 with screw connection <sup>3)</sup>
												Moisture detector/filter
							0	0	)			without filter, without moisture detector
							0	1				without filter, 1 moisture detector with PVDF adapter $^{\scriptscriptstyle 2)}$
							1	0	)			1 filter, without moisture detector
							1	1				1 filter with built-in moisture detector
												Signal outputs
									0	0		status output only
									1	0		Analog output, 420 mA additional
												Delta T control
											0 0	without Delta T control
											10	Delta T control option

<sup>1)</sup> 24 V DC CPsingle not connected electrically.

<sup>2)</sup> Also available in stainless steel.

<sup>3)</sup> Metric or US connection, per heat exchanger.

## 1.5.2 Gas cooler models with one heat exchanger for H2/O2 applications

The item number is a code for the configuration of your unit. Please use the following model code:

96 2 1 1	X 2	Х	1 1	Х	0 0	0 0	JX	0	X 0	Х	Product Characteristics
											Gas cooler models (with 1 heat exchanger)
	1										TC-Standard 6111 X2: Ambient temperature 40 °C
	2										TC-Standard 6112 X2: Ambient temperature 50 °C
											Certifications
	2										for explosive areas
											Supply voltage
		1									115 V AC, 50/60 Hz
		2									230 V AC, 50/60 Hz
											Heat exchanger
			1 1	0						-02	Stainless steel, PTS-O2, metric
			1 1	5						-02	Stainless steel, PTS-I-O2, US
			1 1	0						-H2	Stainless steel, PTS-H2, metric
			1 1	5						-H2	Stainless steel, PTS-I-H2, US
											Signal outputs
							0	0			status output only
							1	0			Analog output, 420 mA, incl. status output
											Delta T control
									0 0		without Delta T control
									10		Delta T control option

## 1.5.3 Gas cooler models with two heat exchangers

The item number is a code for the configuration of your unit. Please use the following model code:

4496 2 1 2 X 2 X 2 X X X 0 X X 0 X 0 0 Product Characteristics

2 X	2	X	2	Х	X	X	0	X   .	X	XU	J .	x U	0	Product Characteristics
														Gas cooler models (with 2 heat exchangers)
1														TC-Standard 6121 X2: Ambient temperature 40 °C
2														TC-Standard 6122 X2: Ambient temperature 50 °C
														Certifications
	2													for explosive areas
														Supply voltage
		1												115 V AC, 50/60 Hz
		2												230 V AC, 50/60 Hz
		4												24 V DC
														Heat exchanger
			2	1	0									Stainless steel, 2 MTS, metric
			2	1	5									Stainless steel, 2 MTS-I, US
			2	2	0									Duran glass, 2 MTG, metric
			2	2	5									Duran glass, 2 MTG-I, US
			2	3	0									PVDF, 2 MTV, metric
			2	3	5									PVDF, 2 MTV-I, US
														Condensate drain <sup>1)</sup>
						0	0							without condensate drain
						2	0							CPdouble X2 with hose nipple, angled
						4	0							CPdouble X2 with screw connection <sup>3)</sup>
														Moisture detector/filter
							(	0	0					without filter, without moisture detector
							(	0	1					without filter, 1 moisture detector with PVDF adapter <sup>2)</sup>
							(	0	2					without filter, 2 moisture detectors with PVDF adapter <sup>2)</sup>
							•	1	0					1 filter, without moisture detector
							•	1	1					1 filter with built-in moisture detector
								2	0					2 filters, without moisture detector
								2	1					2 filters, 1 moisture detector
								2	2					2 filters, 2 moisture detectors
														Signal outputs
										0 0	)			status output only
										1 (	)			Analog output, 420 mA additional
														Delta T control
												0 0		without Delta T control
												1 0		Delta T control option

<sup>1)</sup> 24 V DC CPdouble not connected electrically.

<sup>2)</sup> Also available in stainless steel.

<sup>3)</sup> Metric or US connection, per heat exchanger.

## 1.5.4 Gas cooler model with two heat exchangers in series

The item number is a code for the configuration of your unit. Please use the following model code:

4496 2 1 2 X 2 X 1 X X 0 X X 0 0 0 0 Product Characteristics

496	2   1	1 2	Х	2)	(1	X	X	X	0	Х	Х	Х	0	0	0	Product Characteristics
																Gas cooler models (with 2 in-line heat exchangers)
			1													TC-Standard+ 6121 X2 Ambient temperature 40 °C
			2													TC-Standard+ 6122 X2 Ambient temperature 50 °C
																Certifications
				2												for explosive areas
																Supply voltage
				1	I											115 V AC, 50/60 Hz
				2	2											230 V AC, 50/60 Hz
				Z	ł											24 V DC
																Heat exchanger
					1	2	2	2								Duran glass, 2x MTG-2, metric
					1	2	7	'								Duran glass, 2x MTG-2-I, US
					1	3	2	2								PVDF, 2x MTV-2, metric
					1	3	7	'								PVDF, 2x MTV-2-I, US
																Condensate drain <sup>1)</sup>
								0	0							without condensate drain
								2	0							CPdouble X2 with hose nipple, angled
								4	0							CPdouble X2 with screw connection <sup>3)</sup>
																Moisture detector/filter
										0	0					without filter, without moisture detector
										0	1					without filter, 1 moisture detector with PVDF adapter <sup>2)</sup>
										1	0					1 filter, without moisture detector
										1	1					1 filter with built-in moisture detector
																Signal outputs
												0	0			status output only
												1	0			Analog output, 420 mA additional

<sup>1)</sup> 24 V DC CPdouble not connected electrically.

<sup>2)</sup> Also available in stainless steel.

<sup>3)</sup> Metric or US connection, per heat exchanger.

## 2 Safety instructions

## 2.1 Important notices



The device is suitable for hazardous areas.

This unit may only be used if:

- The product is being used under the conditions described in the operating- and installation instructions, used according to the nameplate and for applications for which it is intended. Any unauthorized modifications to the unit will void the warranty provided by Bühler Technologies GmbH,
- The specifications and markings in the type plate must be observed,
- The threshold values in the data sheet and the instructions must be observed,
- Monitoring equipment / protection devices must be connected correctly,
- Service and repair work not described in these instructions are performed by Bühler Technologies GmbH,
- Genuine replacement parts must be used.
- Erecting electrical systems in explosive areas requires compliance with the following national regulations:
- IEC/EN 60079-14
- National electric code (NEC)
- Canadian electric code (CEC)

Additional national regulations pertaining to initial operation, operation, maintenance, repairs and disposal must be observed.

These operating instructions are a part of the equipment. The manufacturer reserves the right to change performance-, specification- or technical data without prior notice. Please keep these instructions for future reference.

#### Signal words for warnings

DANGER	Signal word for an imminent danger with high risk, resulting in severe injuries or death if not avoided.
WARNING	Signal word for a hazardous situation with medium risk, possibly resulting in severe injuries or death if not avoided.
CAUTION	Signal word for a hazardous situation with low risk, resulting in damaged to the device or the property or minor or medium injuries if not avoided.
NOTICE	Signal word for important information to the product.

#### Warning signs

These instructions include the following warnings:



## 2.2 General hazard warnings

The equipment must be installed by a professional familiar with the safety requirements and risks.

Be sure to observe the safety regulations and generally applicable rules of technology relevant for the installation site. Prevent malfunctions and avoid personal injuries and property damage.

#### The operator of the system must ensure:

- Safety notices and operating instructions are available and observed,
- The respective national accident prevention regulations are observed,
- The permissible data and operational conditions are maintained,
- Safety guards are used and mandatory maintenance is performed,
- Legal regulations are observed during disposal,
- compliance with national installation regulations.

#### Maintenance, Repair

Please note during maintenance and repairs:

- Repairs to the unit must be performed by Bühler authorised personnel.
- Only perform conversion-, maintenance or installation work described in these operating and installation instructions.
- Always use genuine spare parts.
- Do not install damaged or defective spare part. If necessary, visually inspect prior to installation to determine any obvious damage to the spare parts.

Always observe the applicable safety and operating regulations in the respective country of use when performing any type of maintenance.

DANGER	Electrical voltage	
	Electrocution hazard.	
<b>^</b>	a) Disconnect the device from power supply.	
4	b) Make sure that the equipment cannot be reconnected to mains unintentionally.	
	c) The device must be opened by trained staff only.	
	d) Regard correct mains voltage.	



Series TC-St	andard X2	
DANGER	Toxic, corrosive gas/condensate	
	Sample gas/condensate may be hazardous to health.	
	a) If necessary, ensure a safe gas/condensate discharge.	
^	b) Always disconnect the gas supply when performing maintenance or repairs.	
	c) Protect yourself from toxic/corrosive gasses/condensate when performing mainten- ance. Wear appropriate protective equipment.	
DANGER	Explosion hazard	
	Life and explosion risk may result from gas leakage due to improper use.	
$\wedge$	a) Use the devices only as described in this manual.	
<b>EX</b>	b) Regard the process conditions.	
	c) Check tubes and hoses for leakage.	
WARNING	Risk of breakage	
	a) Protect the equipment against being hit.	
	b) Protect the device against falling objects.	

## 3 Transport and storage

Only transport the product inside the original packaging or a suitable alternative.

The equipment must be protected from moisture and heat when not in use. It must be stored in a covered, dry and dust-free room at a temperature of -20 °C to 60 °C (-4 °F to 140 °F).

In particular for sample gas coolers with stainless steel heat exchangers for<sub>02</sub> applications (suffix -O2), it is essential to rule out any contamination of components in contact with the media during storage.

## 4 Installation and connection

### 4.1 Installation site requirements

The unit is only intended for wall-mounted use in enclosed areas. Adequate protection from the weather must be provided when used outdoors.

Install the unit leaving enough room below the cooler to discharge the condensate. Leave room above for the gas supply.

Be sure to maintain the approved ambient temperature. Do not obstruct the convection of the cooler. The vents must have enough room to the next obstacle. The distance must especially be a minimum of 10 cm on the air outlet side.

Ensure adequate ventilation when installing in enclosed housings, e.g. analyser cabinets. If the convection is inadequate, we recommend aerating the cabinet or installing a fan to lower the inside temperature.

#### CAUTION Contamination of cleaned components



For sample gas coolers with stainless steel heat exchangers for  $O_2$  applications (suffix -O2), contamination with oil, grease, dust, particles, lint, hair, etc. must be ruled out for fire protection reasons when working on components that come into contact with media. If necessary, adapt your operational and organisational measures with regard to the work clothing to be used, hygiene regulations, etc. If necessary, move such work to a suitable, cleaner work area.



## 4.2 Installation

Run the gas supply to the cooler with a downward slope. The gas inputs are marked in red and additionally labelled "IN".

If a large amount of condensate accumulates, we recommend using a condensate trap with automatic condensate drain. Our condensate drains, 11 LD V38, AK 20, AK 5.5 OR AK 5.2, are suitable.

Glass vessels and automatic condensate drains are available for draining condensate for external mounting below the unit. When using automatic condensate drains, the sample gas pump must be installed upstream of the cooler (pressure operation) to ensure proper function of the condensate drain.

If the sample gas pump is located at the cooler outlet (suction operation), we recommend using glass condensate traps or peristaltic pumps.

With the option for high-purity water or oxygen (suffix -H2/-O2), the components are each supplied in separate packaging. To prevent soiling, these should only be unpacked shortly before use.

#### Installation instructions additional type plate -H2:

To ensure traceability of the leakage test of the heat exchanger in  $H_2$  applications, affix the enclosed additional type plate in a suitable place before commissioning. When affixing to the cooler housing, no openings must be closed, and overlapping with other stickers or components is not permitted – minimum distance: 20 mm.

#### CAUTION Warning of electrical charge (-H2)



When affixing to the cooler: The enclosed additional type plate of the heat exchanger must be affixed to the cooler according to the installation instructions.

### 4.2.1 Connecting the filter gas connections (optional)

The connection between the heat exchanger outlet and the filter inlet does not have tubing included. The connection G1/4 or NPT 1/4" (filter head marked NPT) for the gas outlet must be carefully and properly connected using a suitable screw connection.

When ordering the cooler with the **option filter without Moisture detector**, a bypass may be connected to the filter head.

The filter head is intended for a G1/4 internal screw thread which is plugged at the factory. To use it, unscrew the plug and screw in a suitable screw connection. Pay attention to leaks.

#### NOTICE



Installing **filters** limits the maximum approved **operating pressure** in the system! Operating pressure ≤ 2 bar

### 4.2.2 Flow adapter connection (optional)

When ordering the cooler with the **option moisture detector without filter**, it will be factory installed inside a flow adapter.

The connection between the heat exchanger outlet and the flow adapter inlet does not have tubing included. The connection G1/4 or NPT 1/4" (flow adapter marked NPT) for the gas inlet/outlet must be carefully and properly connected using a suitable screw connection. Here the direction of flow is not relevant.

## 4.2.3 Connecting the moisture detector (option)

When ordering the cooler with **moisture detector option**, it will be factory installed inside a flow adapter, or for the **filter option** installed and connected in the filter head.

## 4.2.4 Peristaltic pump connector (optional)

Coolers ordered with attached peristaltic pump already have it installed and wired. Heat exchangers ordered at the same time are already installed and connected to the peristaltic pump.

The ø6 mm (0.24 inch) hose nipple for the pump's condensate outlet must be carefully and properly connected with a suitable hose and hose clamp.

Versions with screw connections DN 4/6 or 1/6"-1/4" are supplied with ferrule and knurled nut and must be carefully sealed with appropriate hose.

#### NOTICE




Installing peristaltic **pumps** CPsingle / CPdouble limits the maximum permissible **operating pressure** in the system! Operating pressure ≤ 1 bar

## 4.2.5 Connecting the heat exchanger

The picture on the left shows the schematics for connecting (two) separate heat exchangers.


To minimise gas wash out in the cooler, the two (identical) heat exchangers must be operated in series (right picture). This should be done as follows:

- 1. Gas inlet line to red gas inlet on heat exchanger 2 (pre-cooling).
- 2. Connection between gas outlet on heat exchanger 2 and the red gas inlet on heat exchanger 1 (after-cooling).
- 3. Attaching the final gas output line to the gas outlet on heat exchanger 1.



The gas inputs are marked in red.

On glass heat exchangers, the correct position of the seal is important when connecting the gas lines (see image). The seal consists of a silicone ring with a PTFE sleeve. The PTFE side must face the glass thread.



Pay attention to the appropriate spanner size when selecting fittings for stainless steel heat exchangers.

PTS/PTS-I gas connections: SW 14 or 9/16"

PTS/PTS-I condensate out connections: SW 22

## 4.2.6 Condensate drain connection

Depending on the material, build a connecting line with fittings and tubing or hose between the heat exchanger and condensate drain. For stainless steel, the condensate drain can be hung directly from the connecting tube; for hoses, the condensate drain must be secured separately using a clamp.

The condensate drain can be mounted directly to the heat exchanger.

When choosing the option for high-purity oxygen, make sure to select the suffix -O2.

If the condensate drain 11 LD V 38 is used for high hydrogen concentrations, the system in which it is installed must be tested for leaks.

Condensate lines must always be installed with a slope and a minimum inside diameter of 6 mm (1/4").

The MTG heat exchanger (in coolers with 2 heat exchangers) can only be operated with peristaltic pumps.

## 4.3 Electrical connections

The operator must install an external separator for the device which is clearly assigned to this device.

This separator

- must be located near the device,
- must be easy for the operator to reach,
- must comply with IEC 60947-1 and IEC 60947-3,
- must separate all live conductors and the status output, and
- must not be attached to the power feed.

The mains supply of the device must be fused according to the specifications under technical data.

#### Potential equalization/static charge

Static charges can result in incendive sparking. Avoid static charges. Any conductive parts of the cooler must be grounded!

The housing has a connection for an earth/equipotential bonding conductor. Ensure the housing is adequately earthed (minimum conductor cross-section 4 mm<sup>2</sup>).

Particularly observe the requirements of EN 60079-14!

WARNING	Hazardous electrical voltage	
4	The device must be installed by trained staff only.	
CAUTION	Wrong mains voltage	
	Wrong mains voltage may damage the device. Regard the correct mains voltage as given on the type plate.	
WADNING		
WARNING	High voltage	
4	Damage to the device in case of insulation testing <b>Do not proceed insulation tests with high voltage</b> to the device as a whole!	

#### **Electric strength test**


This device is equipped with extensive EMC protection. The necessary tests were carried out at the factory (test voltage 2.1 kV or 2.55 kV DC depending on approval).

If you wish to check the electric strength again yourself, you can do so on the entire unit. Only test the device with the specified values using direct current voltage. Testing the electric strength with alternating current voltage will damage electronic components. The recommended voltage in this case is 2.1 kV DC, 2 s. Disconnect all supply lines from the device before testing. Power can be supplied via the mains connection.

#### Plug connection

This device has one EN 175301-803 plug each for the power supply and the signal output. If the lead is connected correctly, these cannot be confused. Therefore please be sure to correctly reassemble the plugs after connecting the wires. Below you will find the pin assignments, with the numbers corresponding to those on the plugs:

The supply line cross-sections must be suitable for the rated current. Use a maximum line cross-section of 1.5 mm<sup>2</sup> (AWG 16) and a cable diameter of 8 - 10 mm (0.31 - 0.39 inch).



\* When using the status output with voltage ≥ 33 V AC or ≥ 70 V DC, the protective earth conductor (PE) must be connected.

The clamping area is 8–10 mm (0.31–0.39 inches) in diameter.

### 4.4 Signal outputs

The device provides different status signals. The maximum switching load of the status outputs is limited to 250 V AC/150 V DC, 2 A, 50 VA each.

An alarm is triggered by the status output (S2) if the temperature of the cooler is outside the specified limits. It does not indicate if the alarm was triggered due to excess temperature or insufficient temperature.

The front film has three LEDs:

Marking	Function
S2	High/low temperature, device error
S1	
OP	Normal operation
	S2 S1 OP

The LEDs OP and S2 indicate the device status similar to the status output S2.

If the option "temperature signal" is built in, the unit has a signal output via the analogue output to indicate the actual cooler temperature.

When the moisture detector (optional) is installed, an alarm is activated by the status output (S2) if the moisture is still present in the prepared sample gas. Thereby, no distinction is made between the alarm/cable break triggered by moisture detector 1 or 2. This information is displayed by an error message instead.

The temperature signal can be read via the panel plug (S3) using the M12x1 connector. This plug is located next to the moisture detector connectors at the top of the cooler.

## Description of signal outputs

	Function/contact type	Description	
Regarding	internal changeover contact: max.	the following device statuses	Contact between 3 and 2 closed (alarm)
S2)	250 V AC/150 V DC, 2 A, 50 VA	can be indicated via two switching outputs:	<ul> <li>No mains voltage and/or actual temperat- ure outside the alarm thresholds</li> </ul>
			Contact between 3 and 1 closed (ok)
			<ul> <li>Mains voltage attached + actual temperat- ure within the alarm thresholds</li> </ul>
			with moisture detector option
			Contact between 3 and 2 closed (alarm)
			<ul> <li>The moisture detector registers residual humidity in the sample gas or cable break: Error message</li> </ul>
			Contact between 1 and 3 closed (ok)
			<ul> <li>no residual moisture in measuring gas/no cable break</li> </ul>
Regarding	4-20 mA analogue output		$T_{Cooler}$ = -20 °C $\triangleq$ (-4 °F) -> 4 mA/ 2 V
S3)	(R <sub>Load</sub> <500 Ω)	ure (please use shielded cables)	T <sub>cooler</sub> = 5 °C ≙ (41 °F) -> 9 mA/ 4,5 V
		cablesj	$T_{Cooler}$ = 60 °C $\triangleq$ (140 °F) -> 20 mA/ 10 V

## **5 Operation and control**

NOTICE



The device must not be operated beyond its specifications.

After switching on the cooler the block temperature will be displayed. The display will flash until the block temperature has reached the preset target value (± adjustable alarm range). The status contact is in the Alarm position.

Once the target temperature range has been reached, the temperature will continuously be displayed and the status contact switches over.

If the display flashes during operation or an error message appears, please refer to bullet "Troubleshooting".

Please refer to the data sheet for performance data and maximum ratings.

## 5.1 Description of functions

The cooler is controlled by a microprocessor. With the factory preset the control already incorporates the various characteristics of the built-in heat exchangers.

The programmable display shows the block temperature in the selected display unit (°C / °F) (factory preset °C). Application-specific settings can easily be configured guided by the menu, using the 5 buttons. For one, this applies to the target outlet dew point, which can be set from 2 to 20 °C (36 °F to 68 °F) (factory preset 5 °C/41 °F).

And then the warning thresholds can be adjusted for low and excess temperature. These are set relative to the outlet dew point  $T_a$  setting.

For the low temperature the range is  $\tau_a$  -1 to - 3 K (at a minimum 1 °C/ 34 °F cooling block temperature), for the excess temperature the range is  $\tau_a$  +1 to +7 K. The factory presets for both values are 3 K.

The flashing display and the status relays indicate the conditions are below or above the configured warning range (e.g. after switching on).

The status output can e.g. be used to control the sample gas pump to allow for the gas flow to only be switched on once the permissible cooling range has been reached or shut off the pump in the event of a moisture detector alarm.

The separated condensate can be drained via connected peristaltic pumps or add-on automatic condensate drains.

Fine mesh filters can also be used, which in turn can be installed in optional moisture detectors.

The glass dome allows the dirt level of the filter element to easily be determined.

The moisture detector is easy to remove. This may be required if a condensate enters the cooler due to a malfunction and the peristaltic pump or the automatic condensate drain is unable to remove it.

## 5.2 Delta T control option

Not all applications require an outlet dew point of 5 °C (41 °F). In some applications a higher dew point is sufficient. In other applications a stable outlet dew point doesn't matter, it's enough for the gas to be dry, so if the outlet dew point has an adequate difference in temperature below the ambient temperature.

Here the electronics measure the ambient temperature and regulate the outlet dew point to an adjustable value below it. This extends the potential cooling capacity to the limits of the heat exchanger. Here it's important to note the outlet dew point fluctuates along with the ambient temperature and a stable dew point cannot be a prerequisite for the measurement.

The target temperature range is defined by the ambient temperature, the adjustable temperature difference and the alarm limits. If the block temperature is not within the target range with active Delta T-control, the status message "*dt*" will flash in the display.

**Example:** At a difference of 30 °C (30 K/54 °F), at a set outlet dew point of 5 °C (41 °F) this means the dew point remains stable up to an ambient temperature of approx. 35 °C (95 °F), and the safe drop is only preferred over the ambient temperature with ambient temperature peaks over 35 °C (95 °F). The cooling capacity specified in the cooling capacity graphs at 35 °C (95 °F) is then available at above 35 °C (95 °F).

## 5.3 Use of menu functions

#### Brief description of the operating principle:

The unit is operated using 5 keys. Their functions are:

Button	Section	Functions
<b>↓</b>	Display	<ul> <li>Switches from the measurement display to the main menu</li> </ul>
or	Menu	<ul> <li>Selects the menu item displayed</li> </ul>
ок	Enter	<ul> <li>Applies an edited value or a selection</li> </ul>
<b>A</b>	Display	<ul> <li>temporarily switches to the alternative measurement display (if option installed)</li> </ul>
	Menu	– Back
	Enter	<ul> <li>Increase value or browse selection</li> <li>Note:</li> </ul>
		<ul> <li>Press button 1 x = changes parameter / value by one;</li> </ul>
		<ul> <li>Hold button = fast mode (numerical values only)</li> </ul>
		<ul> <li>Display flashes: modified parameter/value</li> </ul>
		<ul> <li>Steady display: original display/value</li> </ul>
V	Display	<ul> <li>temporarily switches to the alternative measurement display (if option installed)</li> </ul>
	Menu	– Next
	Enter	<ul> <li>Reduce value or browse selection</li> </ul>
ESC	Menu	<ul> <li>Move one level up</li> </ul>
	Enter	<ul> <li>Return to menu</li> <li>Changes will not be saved!</li> </ul>
F		<ul> <li>Sets a menu to favourite.</li> <li>(Note: The favourite menu will also be activated with the menu locked!)</li> </ul>
or		
Func		

## 5.3.1 Lock Menu

Some menus can be locked to prevent inadvertently changing the settings of the unit. This requires setting a code. For information on setting up or disabling the menu lock please refer to "Global Settings" ( $\underline{ko}^{P}$ ) under menu item  $\underline{ko}^{P} > \underline{koc}$ .

The menu lock is **not** enabled at the time of delivery, all menu items can be accessed.

With the menu locked, only the following menu items will be visible without entering the correct code:

Menu item	Explanation
toP > uni t	Temperature unit selection (°C or °F).
F or Func.	Accessing the Favourites menu
	NOTICE! This menu may be one that is normally locked.

### 5.3.2 Menu navigation overview

When pressing the **OK** button in normal mode, the display will show the prompt *codE* if the menu is locked. Use the  $\blacktriangle$  and  $\blacktriangledown$  buttons to enter the correct code and press **OK**.

If an incorrect code or no code is entered, the menu will not be unlocked and you will not be able to access all menu items.

If you forgot the password you can always enter master code 287 to access the menu; the menu will be unlocked.

The following image shows an overview of the menu structure.

Items with a dashed frame will only appear with the respective settings or with the respective status messages.

The factory defaults and settings ranges are specified in the overview as well as under the respective menu item. The factory defaults apply unless otherwise agreed.

You can cancel entries and menu selections without saving by pressing the ESC key.


#### Menu:



#### 1. Menu designation


- 2. Display
- 3. Brief description

Parameter:



#### Optional menu navigation:

- 4. Value input
- 5. Factory preset
- 6. Parameter range
- 7. Selecting from the list of values
- 8. Factory preset
- 9. Parameter range/selection
- 10. dashed box = Optional



### 5.4 Description of menu functions

### 5.4.1 Display menu

#### **Block temperature display**

Display  $\rightarrow chl$ 



Depending on the device state, the temperature will be displayed as a constant, flashing, or alternating with a status message.

#### Ambient temperature display

Display  $\rightarrow ch^2$ 



The display is only available on devices with "Delta-T" option. Depending on the device state, the temperature will be displayed as a constant, flashing, or alternating with a status message.

#### **Operating hours /runtime display**

Display  $\rightarrow oPEr$ 



Displays the operating hours of the unit. The runtime cannot be reset and can be output in various display formats. To view/exit the runtime, press the "Enter" key.

- yynn display in years and months (default)
- *ILh* display in months
- <u>L'EEh</u> display in weeks
- dRYS display in days
- One month corresponds to 30 days. Press the "F" key to switch between the display formats. The display will then first show the selected format as short text, then the duration.

#### Error code display

Display  $\rightarrow E_{cc}$ 



In the event of errors/malfunctions not related to operation, the error code indicates possible causes and solutions.

### 5.4.2 Main menu

#### **Peltier Cooler TC-Standard**

Display  $\rightarrow \frac{1}{2}c.5t$ 



This will take you to the cooler target temperature and the tolerance range setting (alarm threshold).

#### **Global setting**

Display  $\rightarrow \underline{LoP}$  (ToP Settings)



This menu is used to configure the global cooler settings.

#### **Peristaltic Pump**

Display  $\rightarrow P_{u}\Pi P$ 

8.8.8.8	Switching the peristaltic pump on and off.
Parameter range:	naP , aFF
Factory setting:	naP
Note:	Status switches, "ሥባም" flashes.


#### Heat exchanger material selection

 $Display \rightarrow hcho$ 

<b>8.8.8.0</b>	Heat exchanger material selection	
Parameter range:	<mark>と5</mark> (Steel), と6 (Glass), とい (PVDF)	
Factory setting:	<mark>と5</mark> (cooler without heat exchanger), or respective material per configuration	

#### Exit main menu

Display  $\rightarrow E$ 



## 5.4.3 Submenu 1

#### Target temperature

8.8.8	This setting determines the nominal temperature for the cooler temperature.
Parameter range:	2 °C to 20 °C (35.6 °F to 68 °F)
Factory setting:	5 °C (41 °F)
Note:	If the temperature is changed the indicator may blink, until the new operating range has been reached.
	This menu item is hidden if the keylock is enabled.

#### upper alarm limit

Display  $\rightarrow$  Cooler  $\rightarrow R h_{i}$  (Alarm high)

8.8.8.8	Here you can set the upper threshold for the visual signal and the status relay. The alarm limit is set based on the cooler temperature setting.
Parameter range:	1 °C to 7 °C (1.8 °F to 12.6 °F)
Factory setting:	3 °C (5.4 °F)
Note:	This menu item is hidden if the keylock is enabled.

#### lower alarm limit

Display  $\rightarrow$  Cooler  $\rightarrow R$  Lo (Alarm low)

8.8.8.8	Here you can set the lower threshold for the visual signal and the status relay. The alarm limit is set based on the cooler temperature setting.
Parameter range:	-1 °C to -3 °C (-1.8 °F to -5.4 °F)
Factory setting:	-3 °C (-5.4 °F)
Note:	This menu item is hidden if the keylock is enabled.

#### DeltaT

 $\mathsf{Display} \to \mathsf{Cooler} \to \frac{\mathsf{d}\mathsf{k}}{\mathsf{d}\mathsf{k}}$ 

8.8.8	Here you can set the nominal difference with respect to ambient temperature.
Parameter range:	-30 K0 K
Factory setting:	-15 K
Note:	This menu will be hidden if the menu is locked.

#### DeltaT mode

 $\mathsf{Display} \to \mathsf{Cooler} \to \varPi_{odu}$ 

8.0.8.0	Here you can activate or deactivate DeltaT-mode.
Parameter range:	RbSo , dt
Factory setting:	Rb50 (normal operation mode)
Note:	This menu will be hidden if the menu is locked.

#### Exit submenu 1

R

B

Display  $\rightarrow$  Submenu  $\rightarrow \frac{E}{E}$ 

Selecting this will return you to the main menu.

## 5.4.4 Submenu 1 (global settings)

#### **Temperature unit**

Display  $\rightarrow \underline{lop} \rightarrow \underline{un} \underline{l}$ 

0.0.0.8	Used to select the temperature display unit.
Parameter range:	E, F
Factory setting:	E

#### Analog output

Display  $\rightarrow \underline{loP} \rightarrow \underline{Rol}$ 

8.0.9.0.	This submenu is used to specify the settings for analog output 1, see chapter Submenu 2 (Analog Output 1)			
Note:	This menu will be hidden if the menu is locked.			

#### Calibrate moisture detector

Display  $\rightarrow \underline{loP} \rightarrow \underline{h2o}$ 

8.8.0.0	If a moisture detector is installed, calibration can now be performed. To do so, the unit must be flushed with dry gas.		
Note:	Calibration was performed at the factory using ambient air. After replacing the moisture detector a calibration is again required.		
	Calibrating the moisture detector will set the menu $\frac{SE_{P_{T}}}{E_{P_{T}}}$ to $\frac{h_{T}}{h_{T}}$ .		
	This menu will be hidden if the menu is locked.		

If the unit has multiple moisture detectors built in, they will be numbered in the menu. In this case, h20 indicates the first, h202 the second moisture detector. The same applies to setting the sensor sensitivity in menu SEn.

#### Moisture detector sensitivity

Display  $\rightarrow \frac{1}{20}P \rightarrow \frac{5}{20}P$ 

8.8.8.8	If moisture detectors are installed, the sensitivity can be reduced here.			
Parameter range:	hu : high sensitivity Lo: low sensitivity non: no moisture detector			
Factory setting:	hi			
Note:	This menu will be hidden if the menu is locked.			

#### Moisture detector: manual or automatic reset following moisture ingress

Display  $\rightarrow \underline{loP} \rightarrow \underline{hLLc}$ 

(*hLEc* = humidity latch). The setting applies to all connected moisture detectors.

8.8.8	Specifies whether the moisture ingress message must be reset manually or will automatically be re- set after the sensor dries.			
Parameter range:	<b>YE 5</b> : The status will be indicated until the user restarts the device and the pumps will be disabled. <b>ne</b> : The status message will automatically be cleared/the pumps will be released again once mois- ture is no longer detected.			
Factory setting:	no			
Note:	This menu will be hidden if the menu is locked.			

#### Moisture detector: error cleared automatically after cable break

Display  $\rightarrow \frac{b}{b} \rightarrow \frac{b}{b} \leftarrow c$ 

(*bLtc* = broken wire latch). The setting applies to all connected moisture detectors.

8888	Determines whether the cable break alarm must be reset manually or will automatically clear on valid measuring signal.			
Parameter range:	<b>SE5</b> : The status will be indicated until the user restarts the device. Clears the error, and the pumps will be deactivated. no: The error message will disappear. The pumps will be switched on again once the moisture de- tector is reactivated again.			
Factory setting:	YES			
Note:	This menu will be hidden if the menu is locked.			

#### Lock Menu

To protect the menu from unauthorised use, enter a value for the lock code. Menu items can then only be accessed after entering the correct code.

Display  $\rightarrow \underline{Loc}^{P} \rightarrow \underline{Loc}$ 

Parameter range:	0 to 9999	
Factory setting:	0 (keylock cancelled)	
Note: This menu will be hidden if the menu is locked.		
Restart		

Display  $\rightarrow toP \rightarrow rESt$ 

(rESE = restart)

8.8.8	The device will restart, all settings are saved. All error messages will be reset. The moisture detector will be reset, irrespective of the settings in menus <del>h! Ec</del> and hllor.
Parameter range:	<mark>ሄደ5</mark> : Restart. The display will show the software version for the device and returns to measurement display. ምር: Exit menu without restarting.
Note:	The user settings will be saved.

## Note:

#### **Factory settings**

$Display \rightarrow$	$LoP \rightarrow rSL$
-----------------------	-----------------------

0.0.8.0	This setting restores the factory settings.		
Parameter range:	YE5: factory settings restored.		
	no: Exit menu without making changes.		
Factory setting:	no		
Note:	This menu will be hidden if the menu is locked.		

#### Exit submenu 1

Display  $\rightarrow$  Submenu  $\rightarrow E$ 



Selecting this will return you to the main menu.

## 5.4.4.1 Submenu 2 (Analog Output 1)

The analog output will display the actual cooler temperature.

#### **Signal behaviour**

In normal mode (noP) the measuring point will output the actual temperature. For testing purposes you can generate constant values *h*<sub>1</sub>, *L*<sub>0</sub> or *hRLF*. The analogue output will output a constant signal with a value as specified in the table.

Constant	Current output 4 – 20 mA	Voltage output 2 – 10 V	
hi	20 mA	10 V	
П,	12 mA	6 V	
Lo	4 mA	2 V	
noP	4 – 20 mA	2 – 10 V	

After testing, the signal behaviour must be changed back to normal mode ( $n_0 P$ ).



 $Display \rightarrow {\it LoP} \rightarrow {\it Rol} \rightarrow {\it cout}$ 

This setting	determines	how the	analogue	output will	behave.
			01110110 01010	0 0. cp 0. c	

Parameter range:	no <sup>P</sup> = Operation (normal mode), hr , Lo, hRLF
Factory setting:	nap
Note:	This menu will be hidden if the menu is locked.

### Selection -> Output Signal

 $Display \rightarrow {}^{LoP} \rightarrow {}^{Ro} \rightarrow {}^{out}$ 

0.0.8.0	Select the type of output signal.
Parameter range:	<ul> <li>Status output 4 20 mA</li> </ul>
	υ Status output 210 V
Factory setting:	,
Note:	Disconnect meter before switching!
	This menu item is hidden if the keylock is enabled.

#### Exit Submenu 2

Display  $\rightarrow \frac{LoP}{P} \rightarrow \frac{Ro}{I} \rightarrow \frac{E}{E}$ 

Selecting this will return you to submenu 1.

## 5.4.5 Set favourite menu

Use the **F** or **Func** (function) key to set a favourite menu to later open it with just the push of a button.

- Open the menu you wish to set as the favourite. This menu can also be a lockable menu.
- Press the function key for more than 3 sec.

The current menu has been set as the favourite. The display will briefly show the message Func.

- Press **ESC** or *E* (Exit) to return to the display.

To now access the favourite menu, press the **F** or **Func** key.

NOTICE! The favourite menu can also be accessed if the menu is locked.

## 6 Maintenance

The base version of the cooler requires no special maintenance.

However, it may have different options depending on the cooler model. In this case the following routine maintenance is required:

- Option peristaltic pump: Check hoses
- Filter option: Check filter element
- Option moisture detector: Calibrate moisture detector

During maintenance, remember:

- The equipment must be maintained by a professional familiar with the safety requirements and risks.
- Only perform maintenance work described in these operating and installation instructions.
- Observe the respective safety regulations and operating specifications when performing any type of maintenance.
- Always use genuine spare parts.
- For the option for high-purity water or oxygen, only use the explicitly designated replacement items with the suffix -H2 or -O2.

DANGER	Electrical voltage	
	Electrocution hazard.	
•	a) Disconnect the device from power supply.	$\rightarrow$
4	b) Make sure that the equipment cannot be reconnected to mains unintentionally.	
	c) The device must be opened by trained staff only.	
	d) Regard correct mains voltage.	
DANGER	Toxic, corrosive gas/condensate	
	Sample gas/condensate may be hazardous to health.	
	a) If necessary, ensure a safe gas/condensate discharge.	
<b>^</b>	b) Always disconnect the gas supply when performing maintenance or repairs.	
	c) Protect yourself from toxic/corrosive gasses/condensate when performing mainten- ance. Wear appropriate protective equipment.	U

## 7 Service and repair

This chapter contains information on troubleshooting and correction should an error occur during operation.

Repairs to the unit must be performed by Bühler authorised personnel.

Please contact our Service Department with any questions:

#### Tel.: +49 (0) 2102-498955 or your agent

For more information on your custom maintenance and startup services, please visit: https://www.buehler-technologies.com/ service

If the device is not functioning properly after correcting any malfunctions and switching on the power, it must be inspected by the manufacturer. Please send the equipment inside suitable packaging to:

#### Bühler Technologies GmbH

- Reparatur/Service -
- Harkortstraße 29

#### 40880 Ratingen

#### Germany

For devices for  $_{H2}/_{O2}$  applications, seal the gas and condensate path or return it without any parts in contact with the medium.

Please also attach the completed and signed RMA decontamination statement to the packaging. We will otherwise be unable to process your repair order.

You can find the form in the appendix of these instructions, or simply request it by e-mailing:

#### service@buehler-technologies.com.

## 7.1 Troubleshooting

Problem / Malfunction	Possible cause	Action
Condensate inside the gas	<ul> <li>Condensate trap full</li> </ul>	<ul> <li>Empty condensate trap</li> </ul>
outlet	<ul> <li>Valve inside the automatic condensate drain may be stuck</li> </ul>	<ul> <li>Flush in both directions</li> </ul>
	<ul> <li>Cooler overloaded</li> </ul>	<ul> <li>Maintain limits</li> </ul>
Reduced gas flow rate	<ul> <li>Gas circuit clogged</li> </ul>	<ul> <li>Uninstall and clean heat exchanger</li> </ul>
		<ul> <li>if necessary, replace filter element</li> </ul>
	<ul> <li>Condensate outlet iced over</li> </ul>	<ul> <li>Send in unit</li> </ul>
Excess temperature	<ul> <li>Operating point not yet reached</li> </ul>	– Wait (max. 20 min)
	<ul> <li>Cooling outlet too long despite the cooler running</li> </ul>	<ul> <li>Be sure the vents are not covered (heat buildup)</li> </ul>
	<ul> <li>Flow rate / dew point / gas temperature too high</li> </ul>	- Maintain limits / install pre-separator
	<ul> <li>Installed fan stopped</li> </ul>	<ul> <li>Check and replace if necessary</li> </ul>
Insufficient temperature	<ul> <li>Faulty control</li> </ul>	<ul> <li>Send in cooler</li> </ul>

## 7.1.1 Error messages on the display

If an error occurs, the display will read "Err". Press the "A" button to show the error number(s).

Error messages will appear until the unit has been restarted or the error is cleared using the "Func" button. It can only be cleared if the cause for the error has been corrected.

# Causes / Action: The following is a list of the most common causes and actions for the respective error. If the actions listed do not resolve the problem, please contact Service.

Problem/malfunction	Possible cause	Action
No display	– No voltage	<ul> <li>Check the supply cable</li> </ul>
	<ul> <li>Loose connecting cable</li> </ul>	– Check fuse
	– Display failure	<ul> <li>Check connections</li> </ul>
D1.02	(The software version for the display will appear).	<ul> <li>Check connections</li> </ul>
	<ul> <li>Not communicating with the controller</li> </ul>	
perman- ent)		
Error	<ul> <li>An error has occurred</li> </ul>	<ul> <li>Read the error number as described above</li> </ul>
Error 01	<ul> <li>Controller malfunction</li> </ul>	<ul> <li>Clear error (temporary fault)</li> </ul>
		<ul> <li>Disconnect from power for approx. 5 s</li> </ul>
		<ul> <li>Contact service</li> </ul>
<b>Error 03</b>	<ul> <li>Microcontroller fault / MCP2</li> </ul>	<ul> <li>Contact service</li> </ul>
<b>8.8.8.</b> Error 04	<ul> <li>EEPROM error</li> </ul>	<ul> <li>Contact service</li> </ul>
Error 22	<ul> <li>Moisture detector 1 cable break</li> </ul>	<ul> <li>Check moisture detector line</li> </ul>
		<ul> <li>Check moisture detector</li> </ul>
<b>Error 32</b>	<ul> <li>Moisture detector 2 cable break</li> </ul>	<ul> <li>Check moisture detector line</li> </ul>
		<ul> <li>Check moisture detector</li> </ul>
<b>8 8 8 8</b> Error 40	<ul> <li>General error temperature sensor 1 (block tem- perature)</li> </ul>	<ul> <li>Possible sensor failure</li> </ul>
<b>8.8.8.9</b> Error 41	<ul> <li>Low temperature / short-circuit temperature sensor 1</li> </ul>	<ul> <li>Check temperature sensor connection</li> </ul>
<b>8 8 8 8</b> Error 42	<ul> <li>Excess temperature / short-circuit temperature sensor 1</li> </ul>	e – Check temperature sensor connection
<b>8 8 8 8 8 6 1 1 1 1 1 1 1 1 1 1</b>	<ul> <li>Measurement fluctuation temperature sensor 1</li> </ul>	<ul> <li>Check temperature sensor connection</li> </ul>
<b>8 8 8 8</b> Error 50	<ul> <li>General error temperature sensor 2 (reference temperature Delta-T)</li> </ul>	<ul> <li>Possible sensor failure</li> </ul>
<b>8 8 8 Error 51</b>	<ul> <li>Low temperature / short-circuit temperature sensor 2</li> </ul>	<ul> <li>Check temperature sensor connection</li> </ul>
<b>Error 52</b>	<ul> <li>Excess temperature / short-circuit temperature sensor 2</li> </ul>	e – Check temperature sensor connection
<b>8.8.8</b> Error 53	<ul> <li>Measurement fluctuation temperature sensor</li> <li>2</li> </ul>	<ul> <li>Check temperature sensor connection</li> </ul>

Status	text	Possible cause	Action
8.8.8.8	H2o.1	<ul> <li>Moisture alarm moisture detector 1</li> </ul>	<ul><li>Dry</li><li>Check condensate trap</li></ul>
8.8.8.8	H2o.2	<ul> <li>Moisture alarm moisture detector 2</li> </ul>	<ul><li>Dry</li><li>Check condensate trap</li></ul>
8.8.8.8	init	<ul> <li>Initialisation phase</li> </ul>	– Wait
8.8.8.8	PuMP	<ul> <li>Pumps deactivated</li> </ul>	<ul> <li>Reactive pumps via menu</li> </ul>
8.8.8.8	dt	Active Delta T control only: The block temperature is outside the defined temperature range.	<ul> <li>Wait to see if the target temperature will be reached</li> </ul>
		<ul> <li>Cooler is still in the "break-in phase"</li> <li>Fluctuating ambient temperature</li> <li>Insufficient cooling capacity</li> </ul>	<ul> <li>Check the ambient temperature / power supplied</li> <li>Process-related: Adjust alarm limits</li> </ul>
(Flashing)		<ul> <li>Excess/low temperature</li> </ul>	<ul> <li>see chapter "Troubleshooting"</li> </ul>

## 7.2 Safety instructions

- The device must be operated within its specifications.
- All repairs must be carried out by Bühler authorised personnel only.
- Only perform modifications, servicing or mounting described in this manual.
- Only use original spare parts.

# For sample gas coolers with stainless steel heat exchangers for $O_2$ applications (suffix -O2), there are special requirements for avoiding contamination when carrying out maintenance and repair work:

Only use cleaned and undamaged tools. We recommend cleaning with a lint-free cloth, ideally pre-soaked with a mixture of isopropanol and demineralised water for residue-free degreasing.

Only use cleaned, original spare parts (see sections Spare parts and Spare parts and accessories for cooler with -H2/-O2 heat exchanger).

Do not use any parts whose original packaging is damaged.

The use of compressed air is only permitted if it corresponds to at least class 2 in accordance with ISO 8573-1:2010.

DANGER	Electrical voltage	
	Electrocution hazard.	
•	a) Disconnect the device from power supply.	$\rightarrow$
4	b) Make sure that the equipment cannot be reconnected to mains unintentionally.	
	c) The device must be opened by trained staff only.	
	d) Regard correct mains voltage.	
DANGER	Toxic, corrosive gas/condensate	
	Sample gas/condensate may be hazardous to health.	
	a) If necessary, ensure a safe gas/condensate discharge.	
<b>^</b>	b) Always disconnect the gas supply when performing maintenance or repairs.	
	c) Protect yourself from toxic/corrosive gasses/condensate when performing mainten- ance. Wear appropriate protective equipment.	

#### CAUTION

#### Health hazard if the heat exchanger leaks

- The heat exchanger is charged with glycol-based coolant. In the event of a heat exchanger leak:
- a) Avoid contact with the skin and eyes.
- b) In the event of a leak, do not restart the cooler under any circumstances The cooler must be repaired by the manufacturer.

## 7.3 Cleaning and removal of the heat exchanger

Heat exchangers only need to be replaced or maintained if clogged or damaged. If they are clogged, we recommend checking whether using a filter will prevent this in future.

For applications with high-purity acid or hydrogen, we recommend cleaning in accordance with current application-specific standards or using an original replacement heat exchanger.

- Close gas supply.
- Switch off device and disconnect all plugs (e.g. status output connector, supply input, etc.).
- Disconnect gas connections and condensate drain.
- Pull the heat exchanger up and out.
- Clean cleaning nest (hole inside the cooler block), as the heat exchangers are installed with silicone grease.
- Purge the heat exchanger until all contaminants have been removed.
- Lubricate the cooled external surface with silicone grease.
- Reinsert the heat exchanger into the cooling nest with a rotating motion.
- Reconnect the gas supply and condensate drain. The gas inlet is marked red.
- Restore power/gas supply and wait until the unit is ready for operation.
- Open gas supply.

### 7.4 Replacing the hoses of the peristaltic pump (option)

- Close gas supply.
- Switch off device and disconnect all plugs (e.g. connector plug status output, supply input, etc.).
- Disconnect supply and discharge tube on peristaltic pump (observe safety notes!).
- Loosen but do not remove centre knurled nut. Flip down the screw.
- Pull cover up and off.
- Unplug external connections and remove hose.
- Replace hose (Bühler spare part) and install peristaltic pump in reverse order.
- Restore the power and gas supply.

## 7.5 Replacing the filter element (option)

#### Gas leakage



The filter should not be dismantled under pressure. Don't use damaged parts again.

- Close the gas supply.
- Switch off and unplug the device.
- Pull the bracket, holding on to the filter glass.
- Whilst holding the filter head, move the glass back and forth and carefully remove downward.
- Remove the filter element and insert a new one.
- Check for leaks and replace, if necessary.
- Whilst holding the filter head, move the glass back and forth and carefully reattach the filter head, attach the bracket, and ensure it is seated securely.
- Restore the power and gas supply.

#### NOTICE! Please observe legal regulations when disposing of filter elements.

### 7.6 Drying of the moisture detector (option)

The moisture detector must be dried if moisture enters.

- Close the gas supply.
- Switch off and unplug the device.
- Loosen the swivel nut for the moisture detector connection line and disconnect the line.
- Unscrew the moisture detector counter-clockwise and remove.
- Dry moisture detector.
- Reinsert the moisture detector and carefully tighten the screw connection.
- Connect the connection line and tighten the swivel nut.
- Restore the power and gas supply.

## 7.7 Calibration of the moisture detector (option)

- When replacing the moisture detectors, they must be recalibrated.
- Be sure dry gas flows through the cooler.
- Select cooler menu and confirm.



Select menu item moisture detector.



- The display shows (Reset).
- Confirm the display to calibrate the moisture detectors.

For a detailed overview of menu navigation, refer to chapter "Operation and Control".

## 7.8 Replacing the base unit

- Close gas supply.
- Switch off device and disconnect all plugs (e.g. status output connector, supply input, etc.).
- Remove the base unit.
- Remove options/add-ons.
- Install options on the new unit.
- Restore the power and gas supply.

## 7.9 Spare Parts

Please also specify the model and serial number when ordering parts. Upgrade and expansion parts can be found in our catalog. Available spare parts:

ltem no.	Description
9100100007	Display module MCD400
9144050080	Connecting cable controller board display module
9100130380	Microcontroller board MCP2.2
4011000	Flow adapter type G, PVDF G1/4
40110001	Flow adapter type NPT, PVDF NPT 1/4"
4011005	Flow adapter type G, stainless steel, G 1/4
40110051	Flow adapter type NPT, stainless steel, NPT 14"
4111100	Moisture detector FF-3-N, without cable
9144050081	Moisture detector connection cable, 300 mm
9144050082	Moisture detector connection cable, 450 mm
41502999	Filter AGF-PV-30-F2, G1/4
415029991	Filter AGF-PV-30-F2, NPT 1/4"
446590005	Fan, 12 V DC
9100010198	Power board
9100011198	Power board, 24 V DC
9100011187	Controller board
see data sheet 450022	Peristaltic Pumps CPsingle, CPdouble X2

## 7.9.1 Consumables and accessories

ltem no.	Description
4510008	Automatic condensate drain AK 5.2 (pressure operation only)
4510028	Automatic condensate drain AK 5.5 (pressure operation only)
4410004	Automatic condensate drain AK 20 (pressure operation only)
4410001	Automatic condensate drain 11 LD V 38 (pressure operation only)
41030050	Replacement filter element F2; 5-pack
9144050038	Cable for cooler temperature analog output 4 m
4410005	Condensate trap GL1, 0.4 L
44920035012	Condensate pump replacement hose, Tygon (Norprene), angled hose nipple
44920035016	Condensate pump replacement hose, Tygon (Norprene), angled hose nipple and screw connection (metric)
44920035017	Condensate pump replacement hose, Tygon (Norprene), angled hose nipple and screw connection (US)
4381045	Screw connection G1/4 – DN 8/12 for passive condensate connection MTS or MTV(-2)
4381048	Screw connection NPT 1/4" for passive condensate connection MTS-I or MTV(-2)-I

## 7.9.2 Spare parts and accessories for cooler with -H2/-O2 heat exchanger

ltem no.	Description
4410001 (see data sheet 450005)	Automatic condensate drain 11 LD V 38 <sup>1)</sup>
4410001-02 (see data sheet 450005)	Automatic condensate drain 11 LD V 38 optimised for oxygen
see data sheet 400016	Stainless steel pipe fittings for high-purity oxygen applications

<sup>1)</sup> For use with high hydrogen concentrations max. 1.5 bar overpressure.

## 8 Disposal

The heat exchanger is charged with glycol-based coolant.

The applicable national laws must be observed when disposing of the products. Disposal must not result in a danger to health and environment.

The crossed out wheelie bin symbol on Bühler Technologies GmbH electrical and electronic products indicates special disposal notices within the European Union (EU).



The crossed out wheelie bin symbol indicates the electric and electronic products bearing the symbol must be disposed of separate from household waste. They must be properly disposed of as waste electrical and electronic equipment.

Bühler Technologies GmbH will gladly dispose of your device bearing this mark. Please send your device to the address below for this purpose.

We are obligated by law to protect our employees from hazards posed by contaminated devices. Therefore please understand that we can only dispose of your waste equipment if the device is free from any aggressive, corrosive or other operating fluids dangerous to health or environment. **Please complete the "RMA Form and Decontamination Statement", available on our website, for every waste electrical and electronic equipment. The form must be applied to the packaging so it is visible from the outside.** 

Please return waste electrical and electronic equipment to the following address:

Bühler Technologies GmbH WEEE Harkortstr. 29 40880 Ratingen Germany

Please also observe data protection regulations and remember you are personally responsible for the returned waste equipment not bearing any personal data. Therefore please be sure to delete your personal data before returning your waste equipment.

# 9 Appendices

## 9.1 Gas cooler technical data

#### TC-Standard X2

Ready for operation	after max. 10 minutes					
Ambient temperature	5 °C to 50 °C					
Gas output dew temperature preset: adjustable:	5 °C 2 °C20 °C or Delta T control					
•		Della i contro	1			
IP rating Mechanical load	IP 20 Tested based on DNV-GL CG0339 vibration class A (0.7g) 2 Hz-13.2 Hz amplitude ± 1.0 mm 13.2 Hz -100 Hz acceleration					
Housing	Stainless ste	el, brushed				
Packaging dimensions	approx. 355 x	( 220 x 205 mm				
Weight incl. heat exchanger	approx. 7.5 kg approx. 6 kg (for 24 V DC) approx. 9 kg at full expansion stage					
Electrical data	Unit without add-on			Unit with add-on (1 peristaltic pump)		
	24 V DC	230 V AC	115 V AC	24 V DC	230 V AC	115 V AC
	±10%	+5/-10%	+5/-10%	±10%	+5/-10%	+5/-10%
	-	50/60 Hz	50/60 Hz	-	50/60 Hz	50/60 Hz
	5 A	0.6 A	1.2 A	5.5 A	0.7 A	1.4 A
	120 W	110 W /	140 VA	130 W	130 W /	′ 160 VA
Recommended fuse (characteristic: delayed action)	6.3 A	1.25 A	2.5 A	6.3 A	1.25 A	2.5 A
Status output switching capacity	max. 250 V A 2 A, 50 VA, po	,				
Electrical Connections	Plug per EN 1	175301-803				
Gas connections and condensate outlet	Heat exchanger see table "Heat Exchanger Overview" Filter, moisture detector adapter G1/4 or NPT 1/4"					
Parts in contact with media Filter: Moisture detector: Heat exchanger: Peristaltic pump: Tubing:	see "Technical Data - Options" see "Technical Data - Options" see table "Heat Exchanger Overview" see "Technical Data - Options" PTFE/Viton					
Markings:	FM18ATEX00 IECEx FMG 18 FM18US0021	012X: II 3 G Ex eo 3.0005X: Ex ec 1 X/FM18CA0010 5.B.00608/20	nC IIC T4 Gc	PABCD		

### TC-Standard X2 with -H2/-O2 heat exchanger

#### Gas Cooler Technical Data

Gas Cooler Technical Data					
Ready for operation	after max. 10 minutes				
Ambient temperature	5 °C to 50 °C				
Gas outlet dew point preset:	5 °C				
adjustable:	2 °C20 °C or Delta T contro	bl			
IP rating	IP 20				
Mechanical load	Tested based on DNV-GL CG0339 vibration class A (0.7 g) 2–13.2 Hz amplitude ± 1.0 mm 13.2–100 Hz acceleration				
Housing	Stainless steel, brushed				
Packaging dimensions	approx. 355 x 220 x 205 mm				
Weight incl. heat exchanger	approx. 7.5 kg approx. 6 kg (for 24 V DC)				
Electrical data	Unit without add-on				
	24 V DC	230 V AC	115 V AC		
	±10%	+5/-10%	+5/-10%		
	-	50/60 Hz	50/60 Hz		
	5 A	0.6 A	1.2 A		
	120 W	110 W /	′ 140 VA		
Recommended fuse (characteristic: delayed action)	6.3 A	1.25 A	2.5 A		
Status output switching capacity	max. 250 V AC, 150 V DC 2 A, 50 VA, potential-free				
Electrical Connections	Plug per EN 175301-803				
Parts in contact with media Heat exchanger:	see table "Heat Exchanger Overview"				
Markings:	FM18ATEX0012X: II 3 G Ex ec nC IIC T4 Gc IECEx FMG 18.0005X: Ex ec nC IIC T4 Gc FM18US0021X/FM18CA0010X: CL I DIV 2 GP ABCD RU C-DE.HA65.B.00608/20				

#### TC-Standard+ X2

#### Gas Cooler Technical Data

Gas Cooler Technical Data						
Ready for operation	after max. 10 minutes					
Ambient temperature	5 °C to 50 °C					
Gas output dew temperature preset: adjustable:	5 °C 2 °C20 °C					
IP rating	IP 20					
Mechanical load	Tested based on DNV-GL CG0339 vibration class A (0.7g) 2 Hz-13.2 Hz amplitude ± 1.0 mm 13.2 Hz -100 Hz acceleration					
Housing	Stainless stee	el, brushed				
Packaging dimensions	approx. 355 x	220 x 205 mm	l			
Weight incl. heat exchanger	approx. 7.5 kg approx. 6 kg (for 24 V DC) approx. 9 kg at full expansion stage					
Electrical data	Unit without add-on			Unit with add-on (1 peristaltic pump)		
	24 V DC	230 V AC	115 V AC	24 V DC	230 V AC	115 V AC
	±10%	+5/-10%	+5/-10%	±10%	+5/-10%	+5/-10%
	-	50/60 Hz	50/60 Hz	-	50/60 Hz	50/60 Hz
	5 A	0.6 A	1.2 A	5.5 A	0.7 A	1.4 A
	120 W	110 W /	′ 140 VA	130 W	130 W /	/ 160 VA
Recommended fuse (characteristic: delayed action)	6.3 A	1.25 A	2.5 A	6.3 A	1.25 A	2.5 A
Status output switching capacity	max. 250 V AC, 150 V DC 2 A, 50 VA, potential-free					
Electrical Connections	Plug per EN 1	75301-803				
Gas connections and condensate outlet	Heat exchanger see table "Heat Exchanger Overview" Filter, moisture detector adapter G1/4 or NPT 1/4"					
Parts in contact with media Filter: Moisture detector: Heat exchanger: Peristaltic pump: Tubing:	see "Technical Data - Options" see "Technical Data - Options" see table "Heat Exchanger Overview" see "Technical Data - Options" PTFE/Viton					
Markings:	IECEx FMG 18 FM18US0021	12X: II 3 G Ex eo 3.0005X: Ex ec 1 X/FM18CA0010 5.B.00608/20		PABCD		


## 9.2 Technical Data - Options

Analogue Output Cooler Temperature	Technical Data
Signal	4-20 mA or 2-10 V
	corresponds to -20 °C to +60 °C cooler temperature
Connection	M12x1 plug, DIN EN 61076-2-101
Technical Data FF-3-N Moisture Detecto	זס
Ambient temperature	3 °C to 50 °C
max. operating pressure with FF-3-N	2 bar
Material	PVDF, PTFE, epoxy resin, stainless steel 1.4571, 1.4576
Technical Data peristaltic pumps CPsir	gle X2 / CPdouble X2
Ambient temperature	0°C to 50 °C
Flow rate	0.3 L/h (50 Hz) / 0.36 L/h (60 Hz) with standard hose
Vacuum inlet	max. 0.8 bar
Pressure inlet	max.1bar
Outlet pressure	1 bar
Hose	4 x 1.6 mm
Condensate outlet	Hose nipple Ø6 mm
	Screw connection 4/6 (metric), 1/6"-1/4" (US)
Protection class	IP 44
Materials	
Hose:	Norprene (Standard), Marprene, Fluran
Connections:	PVDF
AGF-PV-30-F2 Filter Technical Data	
Ambient temperature	3 °C to 100 °C
max. operating pressure with filter	4 bar
Filter surface	60 cm <sup>2</sup>
Filter fineness	2 μm
Dead volume	57 ml
Materials	
Filter:	PVDF, Duran glass (parts in contact with media)
Seal:	Viton
Filter element:	sintered PTFE

## 9.3 Flow diagrams

### TC-Standard


1 gas path:



1 Cooler	2 Moisture detector (option)
3 Filter (optional)	4 Condensate pump (optional)

#### TC-Standard+


1 in-line gas path:



#### 9.4 Performance curves


#### **TC-Standard**

One heat exchanger	
Model TC-Standard 6111 (X2)	
Rated cooling capacity (at 25 °C)	100 kJ/h
Max. Ambient temperature	40 °C
Dew point fluctuations	
static	± 0.1 K
in the entire specification range	± 1.5 K




#### Model TC-Standard 6112 (X2)

Rated cooling capacity (at 25 °C)	90 kJ/h
Max. Ambient temperature	50 °C
Dew point fluctuations	
static	± 0.1 K
in the entire specification range	± 1.5 K




Two heat exchangers	
Model TC-Standard 6121 (X2)	
Rated cooling capacity (at 25 °C)	100 kJ/h
Max. Ambient temperature	40 °C
Dew point fluctuations	
static	± 0.1 K
in the entire specification range	± 1.5 K
Temperature difference between heat exchangers	

< 0.5 K




#### Model TC-Standard 6122 (X2)

Rated cooling capacity (at 25 °C)	90 kJ/h
Max. Ambient temperature	50 °C
Dew point fluctuations	
static	± 0.1 K
in the entire specification range	± 1.5 K
Temperature difference between heat exchangers	
	< 0.5 K



Note: The limit curves for the heat exchangers exchanger PTG, PTV or MTV apply to a dew point of 40 °C.

#### TC-Standard with -H2/-O2 heat exchanger




#### TC-Standard+

Model TC-Standard+ 6121 (X2)


Rated cooling capacity (at 25 °C)	100 kJ/h
Max. Ambient temperature	40 °C
Dew point fluctuations	
static	± 0.1 K
in the entire specification range	± 1.5 K
Temperature difference between beat exchangers	

Temperature difference between heat exchangers





Rated cooling capacity (at 25 °C)	90 kJ/h
Max. Ambient temperature	50 °C
Dew point fluctuations	
static	± 0.1 K
in the entire specification range	± 1.5 K
Temperature difference between heat exchangers	



Note: The limit curves for the heat exchangers MTV-2 and MTG-2 apply to a dew point of 50 °C.

## 9.5 Heat exchanger

## 9.5.1 Heat exchanger description

The energy content of the sample gas and the required cooling capacity of the gas cooler is determined by three parameters: gas temperature  $\vartheta_{G}$ , dew point  $\tau_{e}$  (moisture content) and volume flow v. The outlet dew point rises with increasing energy content of the gas. The following limits for the maximum flow are specified for a standard operating point of  $\tau_{e}$  = 40 °C and  $\vartheta_{G}$  = 70 °C. The maximum flow  $v_{max}$  in Nl/h of cooled air indicated, so after moisture has condensed. Values may differ for other dew points and gas inlet temperatures. However, the physical facts are so vast we decided to omit the illustration. Please contact our experts for clarification or refer to our calculation programme.

## 9.5.2 Heat exchanger overview

#### **TC-Standard**

Heat exchanger	<b>PTS</b> <b>PTS-I</b> <sup>2)</sup>	PTG PTG-I <sup>2)</sup>	PTV PTV-I <sup>2)</sup>	MTS <sup>3)</sup> MTS-I <sup>2) 3)</sup>	MTG <sup>3)</sup> MTG-I <sup>2) 3)</sup>	MTV <sup>3)</sup> MTV-I <sup>2) 3)</sup>
Materials in contact with media	Stainless steel	Glass PTFE	PVDF	Stainless steel PVDF	Glass PTFE	PVDF
Flow rate v <sub>max</sub> <sup>1)</sup>	450 Nl/h	250 Nl/h	250 Nl/h	300 Nl/h	210 Nl/h	190 Nl/h
Inlet dew point T <sub>e,max</sub> 1)	65 °C	65 °C	65 °C	65 °C	65 °C	65 °C
Gas inlet temperature $artheta_{G,max}$ 1)	180 °C	140 °C	140 °C	140 °C	140 °C	140 °C
Max. Cooling capacity Q <sub>max</sub>	150 kJ/h	90 kJ/h	90 kJ/h	95 kJ/h	80 kJ/h	65 kJ/h
Gas pressure p <sub>max</sub>	160 bar	3 bar	2 bar	25 bar	3 bar	2 bar
Pressure drop Δp (v=150 L/h)	10 mbar	10 mbar	10 mbar	20 mbar	19 mbar	18 mbar
Dead volume V <sub>tot</sub>	29 ml	29 ml	57 ml	19 ml	18 ml	17 ml
Gas connections (metric)	6 mm	GL 14 (6 mm) <sup>4)</sup>	DN 4/6	6 mm tube	GL14 (6 mm)	DN 4/6
Gas connections (US)	1/4"	GL 14 (1/4") <sup>4)</sup>	1/4"-1/6"	1/4" tube	GL14 (1/4")	1/4"-1/6"
Condensate out connections (metric)	G3/8	GL 25 (12 mm) <sup>4)</sup>	G3/8	G1/4	GL18 (8 mm)	G1/4
Condensate out connections (US)	NPT 3/8"	GL 25 (1/2") <sup>4)</sup>	NPT 3/8"	NPT 1/4"	GL18 (8 mm)	NPT 1/4"

<sup>1)</sup> Max. cooling capacity of the cooler must be considered.

<sup>2)</sup> Models marked I have NPT threads or US tubes, respectively.

<sup>3)</sup> Passive discharge via automatic condensate drains or traps not applicable for MTG heat exchangers. For passive discharge on the MTS and MTV heat exchangers, use a screw connection with a clearance of at least 7 mm (see accessories).

<sup>4)</sup> Gasket inside diameter.

#### TC-Standard with -H2/-O2 heat exchanger

Heat exchanger	PTS-H2/-O2 PTS-I-H2/-O2 <sup>2)</sup>
Materials in contact with media	Stainless steel
Flow rate v <sub>max</sub> <sup>1)</sup>	450 Nl/h
Inlet dew point T <sub>e,max</sub> <sup>1)</sup>	65 °C
Gas inlet temperature $artheta_{G,\max}$ 1)	180 °C
Max. cooling capacity Q <sub>max</sub>	150 kJ/h
Gas pressure p <sub>max</sub>	1.5 bar
Pressure drop Δp (v=150 l/h)	10 mbar
Dead volume V <sub>dead</sub>	29 ml
Gas connections (metric)	6 mm
Gas connections (US)	1/4"
Condensate out connection (metric)	G3/8
Condensate out connection (US)	NPT 3/8"

<sup>1)</sup> Max. cooling capacity of the cooler must be considered.

<sup>2)</sup> Models marked I have NPT threads or US tubes.

#### TC-Standard+

Heat exchanger	<b>2x MTG-2</b> <sup>3)</sup> <b>2x MTG-2-I</b> <sup>2)3)</sup>	<b>2x MTV-2</b> <sup>3)</sup> <b>2x MTV-2-I</b> <sup>2) 3)</sup>
Materials in contact with media	Glass PTFE	PVDF
Flow rate v <sub>max</sub> <sup>1)</sup>	210 Nl/h	190 Nl/h
Inlet dew point T <sub>e,max</sub> <sup>1)</sup>	70 °C	70 °C
Gas inlet temperature $artheta_{G,max}$ 1)	140 °C	140 °C
Max. Cooling capacity Q <sub>max</sub>	80 kJ/h	65 kJ/h
Gas pressure p <sub>max</sub>	3 bar	2 bar
Pressure drop Δp (v=150 L/h)	19 mbar	18 mbar
Dead volume V <sub>tot</sub>	38 ml	36 ml
Gas connections (metric)	GL14 (6 mm) <sup>4)</sup>	DN 4/6
Gas connections (US)	GL14 (1/4") 4)	1/4"-1/6"
Condensate out connection (metric)	GL18 (8 mm) 4)	G1/4
Condensate out connection (US)	GL18 (8 mm) 4)	NPT 1/4"

<sup>1)</sup> Max. cooling capacity of the cooler must be considered.


<sup>2)</sup> Models marked I have NPT threads or US tubes, respectively.

<sup>3)</sup> Passive discharge via automatic condensate drains or traps not applicable for MTG-2 heat exchangers. For passive discharge on MTV-2 heat exchangers, use a screw connection with a clearance of at least 7 mm (see accessories).


<sup>4)</sup> Gasket inside diameter.


## 9.6 Dimensions (mm)


#### **TC-Standard**



### TC-Standard with -H2/-O2 heat exchanger









Series TC-Standard X2

#### TC-Standard+





S1 = Electric supply

S2 = Status output

S3 = Analog output

## **10 Attached documents**

- Declaration of Conformity
- O<sub>2</sub> declaration (heat exchanger)
- Certificates
- RMA Decontamination Statement

## EU-Konformitätserklärung EU-declaration of conformity



Hiermit erklärt Bühler Technologies GmbH, dass die nachfolgenden Produkte den wesentlichen Anforderungen der Richtlinie Herewith declares Bühler Technologies GmbH that the following products correspond to the essential requirements of Directive

#### 2014/34/EU (Atex)

in ihrer aktuellen Fassung entsprechen.

in its actual version.

Produkt / products:	Messgaskühler / Sample gas cooler
Typ / type:	TC-Standard X2, TC-MIDI X2, TC-Double X2
10. T.	TC-Standard+ X2, TC-MIDI+ X2, TC-Double+ X2

Die Produkte werden entsprechend der derzeitig gültigen Atex-Richtlinie innerhalb der internen Fertigungskontrolle folgendermaßen gekennzeichnet: The products are marked according to the currently valid Atex directive during internal control of production:

> Atex: 🖾 II 3 G Ex ec nC IIC T4 Gc IECEx: Ex ec nC IIC T4 Gc

Die Eignung dieses Produkts für die Zone 2 wurde durch eine Baumusterprüfbescheinigung mit der Nummer FM18ATEX0012X festgestellt.

Die Betriebsanleitung zu diesem Produkt beinhaltet besondere Installations- und Betriebsbedingungen und sind für die sichere Anwendung zu beachten.

This product's suitability for Zone 2 was determined by type-examination certificate number FM18ATEX0012X.

The operating instructions for this product contains special installation and operating conditions and must be observed to ensure safe operation.

Zur Beurteilung der Konformität wurden folgende harmonisierte Normen herangezogen: For the assessment of conformity the following standards have been used:

EN 60079-0:2012 + A11:2013

#### EN 60079-7:2015+A1:2018

EN 60079-15:2018

Der Hersteller hat die Übereinstimmung des Gerätes mit aktuelleren Normenausgaben als in der Baumusterprüfbescheinigung aufgeführt geprüft und die Konformität festgestellt: The manufacturer has checked the compliance of the device with more current standards than those listed in the type examination certificate and has established conformity:

EN IEC 60079-0:2018

#### EN IEC 60079-7:2015 + A1:2018

Dokumentationsverantwortlicher für diese Konformitätserklärung ist Herr Stefan Eschweiler mit Anschrift am Firmensitz.

The person authorised to compile the technical file is Mr. Stefan Eschweiler located at the company's address.

Ratingen, den 01.03.2021

Stefan Eschweiler Geschäftsführer – Managing Director

Frank Pospiech Geschäftsführer – Managing Director

Bühler Technologies GmbH, Harkortstr. 29, D-40880 Ratingen, Tel. +49 (0) 21 02 / 49 89-0, Fax. +49 (0) 21 02 / 49 89-20 Internet: www.buehler-technologies.com

KX 44 0010



# O2-Erklärung O2 Declaration

## Wärmetauscher für den Einsatz mit hochreinem Sauerstoff optimiert

Heat Exchanger optimised for use with high-purity oxygen

Applikationen mit Sauerstoff: Partikel-, Öl- und Fettfreiheit

Mit dieser Erklärung bestätigen wir, dass alle medienberührenden Flächen der nachfolgenden Produkte in Anlehnung an die Vorgaben der EIGA Doc 33/18 und des VDA-Band 19 gereinigt und gefertigt sind.

#### Applications with oxygen: free of particles, oil and grease

With this declaration, we confirm that all surfaces of the following products that come into contact with media have been cleaned and manufactured in accordance with the specifications of EIGA Doc 33/18 and VDA Volume 19.

Produkt / Products	Wärmetauscher / Heat Exchanger	Art-Nr. / Item no.:
Typen / Types:	PTS-O2	4447999-02
	PTS-I-O2	44489991-02
	TS-O2	4510023-02
	TS-I-O2	4510025I-O2
	DTS-O2	4501026-02
	DTS-I-O2	4501026I-O2

Ratingen, den 25.04.2024 Bühler Technologies GmbH

7-FY

**32 Declarati** 



Gas Analysis

## Applications with oxygen: Free from particles, oil and grease



For use with high-purity oxygen, the product requires special cleaning to ensure that it is free from oil and grease, as oxygen is a strong oxidising agent. Under unfavourable conditions, oxygen can cause spontaneous combustion of organic substances such as particles, oils and fats, and generally promotes the combustion of substances. Oils and fats can even react explosively on contact with oxygen. We use special cleaning and production processes to ensure the safe use of our products with high-purity oxygen and to avoid the above-mentioned undesirable reactions.

With this declaration, we confirm that all surfaces of the following products that come into contact with media have been cleaned and manufactured in accordance with the requirements of EIGA Doc 33/18 and VDA Volume 19.

Product:	Heat exchanger	ltem no.
Models:	PTS-O2	4447999-O2
	PTS-I-O2	4448999I-O2
	TS-O2	4510023-O2
	TS-I-O2	45100251-02
	DTS-O2	4501026-02
	DTS-I-O2	45010261-02

The material used for the "O2" heat exchangers is high-quality stainless steel, which has been tested by Bühler Technologies for its suitability for oxygen applications.

All components in contact with the medium undergo a special cleaning process to reliably remove impurities (such as oil, grease and particles). This process is documented by a comprehensive delivery specification to the service provider and compliance with the limits is verified with regular analyses by an independent, accredited laboratory.

The contamination limits of the surfaces in contact with media are defined as follows (as in EIGA Doc 33/18 Cleaning of Equipment for oxygen service):

	Contamination limits
Non-volatile organic or inorganic impurities:	≤ 220 mg/m <sup>2</sup> for non-volatile impurities
Particles:	$\leq$ 22 particles/m <sup>2</sup> between 500 µm and 1000 µm

The component groups of the heat exchangers are cleaned by an external service provider and then manufactured into the end product at Bühler Technologies. After these production steps, the heat exchanger is undergoes final cleaning by the service provider before delivery in order to remove any contamination from the production process.

Compliance with the contamination limits is documented by the external service provider by means of factory test certificates (free of oil and grease) and a test report (free of dust and dirt). After cleaning, the heat exchangers are packed in airtight and dustproof packaging and clearly labeled "Cleaned for oxygen service. Do not open until ready for use".

All described cleaning properties are lost if the product comes into contact with oily or greasy media or is otherwise contaminated from the outside.



# **CERTIFICATE OF CONFORMITY**



- 1. HAZARDOUS LOCATION ELECTRICAL EQUIPMENT PER CANADIAN REQUIREMENTS
- 2. Certificate No:
- 3. Equipment: (Type Reference and Name)
- 4. Name of Listing Company:
- 5. Address of Listing Company:

FM18CA0010X

TC-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas Cooler Bühler Technologies GmbH

Harkortstrasse 29 Ratingen, D-40880 Germany

6. The examination and test results are recorded in confidential report number:

3062014 dated 4th October 2018

7. FM Approvals LLC, certifies that the equipment described has been found to comply with the following Approval standards and other documents:

CSA-C22.2 No. 213-15, CAN/CSA-C22.2 No. 61010-1:2012

- 8. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 9. This certificate relates to the design, examination and testing of the products specified herein. The FM Approvals surveillance audit program has further determined that the manufacturing processes and quality control procedures in place are satisfactory to manufacture the product as examined, tested and Approved.
- 10. Equipment Ratings:

#### TC-Standard Models:

Non-incendive for Class I, Division 2, Groups A, B, C and D; T4 hazardous locations with an ambient temperature rating of 0°C of up to 50°C.

Certificate issued by:

Marguerdi

J/E. Marquedant VP, Manager, Electrical Systems

4 October 2018 Date

To verify the availability of the Approved product, please refer to www.approvalguide.com

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE





#### Canadian Certificate Of Conformity No: FM18CA0010X

#### TC-MIDI and TC-Double Models:

Non-incendive for Class I, Division 2, Groups A, B, C and D; T4 hazardous (classified) locations with an ambient temperature rating of 0°C of up to 60°C.

11. The marking of the equipment shall include:

#### TC-Standard Models:

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

#### TC-MIDI and TC-Double Models:

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

#### 12. **Description of Equipment:**

**General** - The TC-6 sample gas chillers are intended to cool and dry the sample gas before going into the gas analysers. Sample gases contain vapour which has to be withdrawn before it reaches the gas analyser. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a preset temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

Construction – The equipment is housed in a brushed stainsteel IP20 enclosure.

**Ratings** - TC-Standard operate at 24VDC, 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 50°C. and TC-MIDI and TC-Double Models operate at 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 60°C.

#### 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

- b = Gas cooler model: 1 or 2
- d, = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Peristaltic Pumps; 0, 1, 3
- j & k = Moisture detector / Filter; 00, 01,10, or 11
- I = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

#### 4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Peristaltic Pumps; 0, 2, or 4
- j & k = Moisture detector / Filter; 00, 01,02, 10, 11, 20, 21, 22

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

## **SCHEDULE**



Canadian Certificate Of Conformity No: FM18CA0010X

I = Status Outputs; 0 or 1

n = Delta T control; 0 or 1

4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 22, 27, 32 & 37
- h = Peristaltic Pumps; 0, 2, 4
- j & k = Moisture detector / Filter; 00, 01,10, or 11
- I = Status Outputs; 0 or 1
- n = no value assigned.

#### 4496 311 b2defghijklmno Thermoelectric Cooler, TC-MIDI + X2(fitted with 1 heat exchangers)

- b = Gas cooler types 1 or 2
- d = Supply Voltage; 1 or 2
- e = Gas paths; 1or 2
- f,g = Heat exchangers; 60,61, 65, 66, 70, 75, 80 or 85
- h = Peristaltic pumps; 0, 2, or 4
- i = Sample gas pumps; 0, 1, 2, 6, or 7
- j,k = Moisture detector / Filter; 00, 01, 02, 10, 11, 20 21, or 22
- l,m = Status output; 00 or 10
- n,o = Delta T control; 00 or 10

4496 312 b2d1fghijklm00 Thermoelectric Cooler, TC-MIDI + X2(fitted with 2 heat exchangers)

- b = Gas cooler types 1 or 2
- d = Supply Voltage; 1 or 2
- f,g = Heat exchangers; 22, 27, 32, or 37
- h = Peristaltic pumps; 0, 2, or 4
- = Sample gas pumps; 0, 1, 2, 6, or 7
- j,k = Moisture detector / Filter; 00, 01, 02, 10, or 11
- I,m = Status output; 00 or 10

#### 4496 611a2c1efghijkl000 Thermoelectric Cooler, TC-Double X2

- a = Gas cooler types 1 or 2
- c = Voltage; 1 or 2
- e,f = Heat exchangers; 10,15, 20,25,30, or 35
- g = Peristaltic pumps; 0, 2, or 4
- h = Sample gas pumps; 0, 1, or 2
- i,j = Moisture Detector/Filter; 00, 01, 10, or 11
- k,I = Status output; 00 or 10

#### 4496 611a2c1efghijkl000 Thermoelectric Cooler, TC-Double+ X2

- a = Gas cooler types 1 or 2
- c = Voltage; 1 or 2
- e,f = Heat exchangers; 22, 27, 32, or 37
- g = Peristaltic pumps; 0, 2, or 4
- h = Sample gas pumps; 0, 1, or 2
- i,j = Moisture Detector/Filter; 00, 01, 10, or 11
- k,I = Status output; 00 or 10

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE





Canadian Certificate Of Conformity No: FM18CA0010X

#### 13. Specific Conditions of Use:

1. When installed as Class I Division 2 equipment, the thermoelectric cooler shall be mounted within a tool-secured IP54 enclosure.

#### 14. Test and Assessment Procedure and Conditions:

This Certificate has been issued in accordance with FM Approvals Canadian Certification Scheme.

#### 15. Schedule Drawings

A copy of the technical documentation has been kept by FM Approvals.

#### 16. Certificate History

Details of the supplements to this certificate are described below:

Date	Description	-	U.
4 <sup>th</sup> October 2018	Original Issue.		1

**Approvals** 

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

## **CERTIFICATE OF CONFORMITY**

# **F** Approvals

#### **1. HAZARDOUS LOCATION ELECTRICAL EQUIPMENT PER CANADIAN REQUIREMENTS**

- 2. Certificate No:
- 3. Equipment: (Type Reference and Name)
- 4. Name of Listing Company:
- 5. Address of Listing Company:

FM18CA0010X

TC-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC-MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas cooler

Bühler Technologies GmbH

Harkortstraße 29, Ratingen D-40880, Germany

6. The examination and test results are recorded in confidential report number:

### 3062014 dated 4<sup>th</sup> October 2018

7. FM Approvals LLC, certifies that the equipment described has been found to comply with the following Approval standards and other documents:

CSA C22.2 No. 213:2021, CSA C22.2 No. 61010-1:2019

- 8. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 9. This certificate relates to the design, examination and testing of the products specified herein. The FM Approvals surveillance audit program has further determined that the manufacturing processes and quality control procedures in place are satisfactory to manufacture the product as examined, tested and Approved.

10. Equipment Ratings:

#### **TC-Standard**

Nonincendive for Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

<u>TC-Midi & TC Double</u> Nonincendive for Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

Certificate issued by:

J.E. Marquerdint

9 October 2024

J.E. Marquedant VP, Manager - Electrical Systems

Date

To verify the availability of the Approved product, please refer to <u>www.approvalguide.com</u>

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>



#### <u>SCHEDULE</u>

Canadian Certificate of Conformity No: FM18CA0010X

#### 11. The marking of the equipment shall include:

#### TC-Standard

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

#### TC-Midi & TC Double

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

#### 12. Description of Equipment:

**General** - The TC- Standard; TC-MIDI & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analyzers. Sample gases contain vapor which has to be withdrawn before it reaches the gas analyzer. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-MIDI X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-MIDI+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimize wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimize wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

**Construction** – The equipment is housed in a brushed stainless-steel IP20 enclosure.

**Ratings** - TC-Standard operate at 24VDC, 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 50°C. and TC-MIDI and TC-Double Models operate at 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 60°C.

See Annex for Model Codes

#### 13. Specific Conditions of Use:

1. When installed as Class I Division 2 equipment, the thermoelectric cooler shall be mounted within a toolsecured IP54 enclosure which is capable of accepting one or more of the Class I Division 2 wiring methods per the Canadian Electric Code (CSA C22.1).

To verify the availability of the Approved product, please refer to www.approvalguide.com

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

SCC Accentited CB-PyS OCPS Accentite CCN

**F** Approvals

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

#### **SCHEDULE**



Canadian Certificate of Conformity No: FM18CA0010X

#### 14. Test and Assessment Procedure and Conditions:

This Certificate has been issued in accordance with FM Approvals Canadian Certification Scheme.

#### 15. Schedule Drawings

A copy of the technical documentation has been kept by FM Approvals.

#### 16. Certificate History

Details of the supplements to this certificate are described below:

Date	Description
4th October 2018	Original Issue.
9 October 2024	Supplement 1:Report Reference: RR242035 dated 9 October 2024.Description of the Change(s):1. Addition of product variants due to changes to electronics2. CSA C22.2 No. 213:2015 updated to CSA C22.2 No. 213:20213. CSA C22.2 No. 61010-1:2012 updated to CSA C22.2 No. 61010-1:2019

To verify the availability of the Approved product, please refer to www.approvalguide.com

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE







SCHEDULE Canadian Certificate of Conformity No: FM18CA0010X

# ANNEX

# 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

#### **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35 h = Condensate drain; 00, 10 or 30 j & k = Moisture detector/Filter; 00, 01,10, or 11 I = Status Outputs; 00 or 10n = Delta T control; 00 or 10

# 4496 211b2d1fg0000l0n0p TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchanger for H2/02 applications)

#### **Description of Equipment:**

 $b = Gas \ cooler \ model: 1 \ or \ 2 \\ d = Supply \ voltage; 1 \ or \ 2 \\ f, g = Heat \ exchanger; 10, 15, 10 \ or \ 15 \\ l = Status \ Outputs; \ 00 \ or \ 10 \\ n = Delta \ T \ control; \ 00 \ or \ 10 \\ p = heat \ exchanger \ optimized \ for \ high-purity \ hydrogen/oxygen; \ -H2 \ or \ -O2$ 

# 4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

#### **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35 h = Condensate drain; 0, 2, or 4 j & k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21, 22 l = Status Outputs; 0 or 1 n = Delta T control; 0 or 1

To verify the availability of the Approved product, please refer to <u>www.approvalguide.com</u>

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com\_www.fmapprovals.com</u>





SCHEDULE Canadian Certificate of Conformity No: FM18CA0010X

# 4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

#### **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 22, 27, 32 or 37 h = Condensate drain; 0, 2, 4 j & k = Moisture detector/Filter; 00, 01,10, or 11 l = Signal Outputs; 0 or 1n = no value assigned.

### 4496 311 b2defghijklmno TC-MIDI X2(fitted with 1 heat exchangers)

#### **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 e = Gas path; 1 or 2 f,g = Heat exchangers; 10, 15, 20, 25, 30 or 35 h = Condensate drain; 0, 1 or 3 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 10 or 11 l,m = Signal output; 00 or 10 n,o = Delta T control; 00 or 10

# 4496 311 b2defg0000lmnop TC-MIDI X2 (fitted with 1 heat exchangers for H2/02 applications)

#### **Description of Equipment:**

b = Gas cooler types 1 or 2

- d = Supply Voltage; 1 or 2
- e = Gas path; 1 or 2
- f,g = Heat exchangers; 10, 15, 60, 65
- l,m = Signal output; 00 or 10
- n,o = Delta T control; 00 or 10
- p = heat exchanger optimized for high-purity hydrogen/oxygen; -H2 or -O2

To verify the availability of the Approved product, please refer to www.approvalguide.com

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

**F** Approvals

SCHEDULE Canadian Certificate of Conformity No: FM18CA0010X

## 4496 312 b2d1fghijklm00 TC-MIDI + X2(fitted with 2 heat exchangers)

#### **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 f,g = Heat exchangers; 60, 65, 61, 66, 70, 75, 80 or 85 h = Condensate drain; 0, 2, or 4 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21 or 22 l,m = Signal outputs; 00 or 10 n, o = Delta T Control; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double X2

#### **Description of Equipment:**

a = Gas cooler types 1 or 2 c = Voltage; 1 or 2 e,f = Heat exchangers; 10, 15, 20, 25, 30 or 35 g = Condensate drain; 0, 2, or 4 h = Sample gas pumps; 0, 1, or 2 i,j = Humidity sensor/Filter; 00, 01, 10, or 11 k,l = Signal outputs; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double+ X2

#### **Description of Equipment:**

- a = Gas cooler types 1 or 2
- c = Voltage; 1 or 2
- e,f = Heat exchangers; 22, 27, 32, or 37
- g = Peristaltic pumps; 0, 2, or 4
- h = Sample gas pumps; 0, 1, or 2
- i,j = Moisture Detector/Filter; 00, 01, 10, or 11
- k,I = Status output; 00 or 10

To verify the availability of the Approved product, please refer to <u>www.approvalguide.com</u>

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>



# **CERTIFICATE OF CONFORMITY**



#### 1. HAZARDOUS (CLASSIFIED) LOCATION ELECTRICAL EQUIPMENT PER US REQUIREMENTS

- 2. Certificate No:
- 3. Equipment: (Type Reference and Name)
- 4. Name of Listing Company:
- 5. Address of Listing Company:

FM18US0021X

C-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas cooler Bühler Technologies GmbH

Harkortstrasse 29 Ratingen, D-40880 Germany

6. The examination and test results are recorded in confidential report number:

3062014 dated 4th October 2018

7. FM Approvals LLC, certifies that the equipment described has been found to comply with the following Approval standards and other documents:

FM Class 3600:2018, FM Class 3611:2018, FM Class 3810:2018, ANSI/ISA-12.12.01-2015, ANSI/ISA 61010-1:2012

- 8. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 9. This certificate relates to the design, examination and testing of the products specified herein. The FM Approvals surveillance audit program has further determined that the manufacturing processes and quality control procedures in place are satisfactory to manufacture the product as examined, tested and Approved.
- 10. Equipment Ratings:

#### TC-Standard Models:

Non-incendive for Class I, Division 2, Groups A, B, C and D; T4 hazardous (classified) locations with an ambient temperature rating of 0°C to 50°C.

Certificate issued by:

Marguerali

J/E. Marquedant VP, Manager, Electrical Systems

4 October 2018 Date

To verify the availability of the Approved product, please refer to www.approvalguide.com

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. 1151 Boston-Providence Turnpike, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

F 347 (Mar 16)

Page 1 of 4





III IIV AIS

US Certificate Of Conformity No: FM18US0021X

#### TC-MIDI and TC-Double Models:

Non-incendive for Class I, Division 2, Groups A, B, C and D; T4 hazardous (classified) locations with an ambient temperature rating of 0°C to 60°C.

11. The marking of the equipment shall include:

#### TC-Standard Models:

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

#### TC-MIDI and TC-Double Models:

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

#### 12. Description of Equipment:

**General** - The TC- Standard; TC-Midi & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analyzers. Sample gases contain vapor which has to be withdrawn before it reaches the gas analyzer. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-Midi X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-Midi+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimize wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimize wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

Construction – The equipment is housed in a brushed stainsteel IP20 enclosure.

**Ratings** - TC-Standard operate at 24VDC, 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 50°C. and TC-MIDI and TC-Double Models operate at 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 60°C.

# 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. 1151 Boston-Providence Turnpike, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

F 347 (Mar 16)





#### US Certificate Of Conformity No: FM18US0021X

- b = Gas cooler model: 1 or 2
- d, = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Peristaltic Pumps; 0, 1, 3
- j & k = Moisture detector / Filter; 00, 01,10, or 11
- = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Peristaltic Pumps; 0, 2, or 4
- j & k = Moisture detector / Filter; 00, 01, 02, 10, 11, 20, 21, 22
- = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

## 4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 22, 27, 32 & 37
- h = Peristaltic Pumps; 0, 2, 4
- j & k = Moisture detector / Filter; 00, 01,10, or 11
- = Status Outputs; 0 or 1
- n = no value assigned.

Т


# 4496 311 b2defghijklmno Thermoelectric Cooler, TC-MIDI + X2(fitted with 1 heat exchangers)

- b = Gas cooler types 1 or 2
- d = Supply Voltage; 1 or 2
- e = Gas paths; 1or 2
- f,g = Heat exchangers; 60,61, 65, 66, 70, 75, 80 or 85
- h = Peristaltic pumps; 0, 2, or 4
  - = Sample gas pumps; 0, 1, 2, 6, or 7
- j,k = Moisture detector / Filter; 00, 01, 02, 10, 11, 20 21, or 22
- l,m = Status output; 00 or 10
- n,o = Delta T control; 00 or 10

4496 312 b2d1fghijklm00 Thermoelectric Cooler, TC-MIDI + X2(fitted with 2 heat exchangers)

- b = Gas cooler types 1 or 2
- d = Supply Voltage; 1 or 2
- f,g = Heat exchangers; 22, 27, 32, or 37
- h = Peristaltic pumps; 0, 2, or 4
- = Sample gas pumps; 0, 1, 2, 6, or 7
- j,k = Moisture detector / Filter; 00, 01, 02, 10, or 11
- I,m = Status output; 00 or 10

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



#### 16. Certificate History

Details of the supplements to this certificate are described below:

Date	Description	10	UV	U
4 <sup>th</sup> October 2018	Original Issue.			

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

# **CERTIFICATE OF CONFORMITY**



#### 1. HAZARDOUS (CLASSIFIED) LOCATION ELECTRICAL EQUIPMENT PER US REQUIREMENTS

- 2. Certificate No:
- 3. Equipment: (Type Reference and Name)
- 4. Name of Listing Company:
- 5. Address of Listing Company:

FM18US0021X

TC-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas cooler Bühler Technologies GmbH

Harkortstrasse 29 Ratingen, D-40880 Germany

6. The examination and test results are recorded in confidential report number:

3062014 dated 4th October 2018

7. FM Approvals LLC, certifies that the equipment described has been found to comply with the following Approval standards and other documents:

FM Class 3600:2018, FM Class 3611:2018, FM Class 3810:2018, ANSI/ISA-12.12.01-2015, ANSI/ISA 61010-1:2012

- 8. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 9. This certificate relates to the design, examination and testing of the products specified herein. The FM Approvals surveillance audit program has further determined that the manufacturing processes and quality control procedures in place are satisfactory to manufacture the product as examined, tested and Approved.
- 10. Equipment Ratings:

**TC-Standard Models:** 

Non-incendive for Class I, Division 2, Groups A, B, C and D; T4 hazardous (classified) locations with an ambient temperature rating of 0°C to 50°C.

Certificate issued by:

Margueralio

J**L**E. Marquedant VP, Manager - Electrical Systems

25 January 2021 Date

To verify the availability of the Approved product, please refer to www.approvalguide.com

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. 1151 Boston-Providence Turnpike, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

F 347 (Mar 16)

Page 1 of 5





VIII VAIS

US Certificate Of Conformity No: FM18US0021X

#### TC-MIDI and TC-Double Models:

Non-incendive for Class I, Division 2, Groups A, B, C and D; T4 hazardous (classified) locations with an ambient temperature rating of 0°C to 60°C.

11. The marking of the equipment shall include:

#### **TC-Standard Models:**

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

#### TC-MIDI and TC-Double Models:

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

#### 12. Description of Equipment:

**General** - The TC- Standard; TC-Midi & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analyzers. Sample gases contain vapor which has to be withdrawn before it reaches the gas analyzer. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-Midi X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-Midi+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimize wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimize wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

**Construction** – The equipment is housed in a brushed stainsteel IP20 enclosure.

**Ratings** - TC-Standard operate at 24VDC, 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 50°C. and TC-MIDI and TC-Double Models operate at 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 60°C.

# 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE





#### US Certificate Of Conformity No: FM18US0021X

- b = Gas cooler model: 1 or 2
- d, = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Peristaltic Pumps; 0, 1, 3
- j & k = Moisture detector / Filter; 00, 01,10, or 11
- = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Peristaltic Pumps; 0, 2, or 4
- j & k = Moisture detector / Filter; 00, 01, 02, 10, 11, 20, 21, 22
- = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

T

## 4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 22, 27, 32 & 37
- h = Peristaltic Pumps; 0, 2, 4
- j & k = Moisture detector / Filter; 00, 01,10, or 11
- = Status Outputs; 0 or 1
- n = no value assigned.


# 4496 311 b2defghijklmno Thermoelectric Cooler, TC-MIDI X2(fitted with 1 heat exchangers)

- b = Gas cooler types 1 or 2
- d = Supply Voltage; 1 or 2
- e = Gas paths; 1or 2
- f,g = Heat exchangers; 60,61, 65, 66, 70, 75, 80 or 85
- h = Peristaltic pumps; 0, 2, or 4
  - = Sample gas pumps; 0, 1, 2, 6, or 7
- j,k = Moisture detector / Filter; 00, 01, 02, 10, 11, 20 21, or 22
- I,m = Status output; 00 or 10
- n,o = Delta T control; 00 or 10

4496 312 b2d1fghijklm00 Thermoelectric Cooler, TC-MIDI + X2(fitted with 2 heat exchangers)

- b = Gas cooler types 1 or 2
- d = Supply Voltage; 1 or 2
- f,g = Heat exchangers; 22, 27, 32, or 37
- h = Peristaltic pumps; 0, 2, or 4
- i = Sample gas pumps; 0, 1, 2, 6, or 7
- j,k = Moisture detector / Filter; 00, 01, 02, 10, or 11
- I,m = Status output; 00 or 10

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



#### 15. Schedule Drawings

A copy of the technical documentation has been kept by FM Approvals.

....

#### 16. Certificate History

Details of the supplements to this certificate are described below:

Date	Description
4 <sup>th</sup> October 2018	Original Issue.
25 <sup>th</sup> January 2021	Supplement 1: Report Reference: RR226270 dated 25 <sup>th</sup> January 2021. Description of the Change: Add digital interface and correct typo in model code to remove + for TC-MIDI fitted with 1 heat exchanger.

#### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



US Certificate Of Conformity No: FM18US0021X

## **FM Approvals**

## **FM Approvals**

FM Approvals

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. 1151 Boston-Providence Turnpike, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

## **CERTIFICATE OF CONFORMITY**

## FM Approvals

## 1. HAZARDOUS (CLASSIFIED) LOCATION ELECTRICAL EQUIPMENT PER US REQUIREMENTS

- 2. Certificate No:
- 3. Equipment: (Type Reference and Name)
- 4. Name of Listing Company:
- 5. Address of Listing Company:

FM18US0021X

TC-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC-MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas cooler

**Bühler Technologies GmbH** 

Harkortstraße 29, Ratingen D-40880, Germany

6. The examination and test results are recorded in confidential report number:

## 3062014 dated 4<sup>th</sup> October 2018

7. FM Approvals LLC, certifies that the equipment described has been found to comply with the following Approval standards and other documents:

FM 3600:2022, FM 3611:2021, FM 3810:2021, ANSI/UL 61010-1:2019, ANSI/UL 121201:2021

- 8. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 9. This certificate relates to the design, examination and testing of the products specified herein. The FM Approvals surveillance audit program has further determined that the manufacturing processes and quality control procedures in place are satisfactory to manufacture the product as examined, tested and Approved.

10. Equipment Ratings:

## **TC-Standard**

Nonincendive for Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

<u>TC-Midi & TC Double</u> Nonincendive for Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

Certificate issued by:

9.8. Marquerchint

9 October 2024

J.E. Marquedant VP, Manager - Electrical Systems

Date

To verify the availability of the Approved product, please refer to <u>www.approvalguide.com</u>

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com\_www.fmapprovals.com</u>



F 347 (Ju**l** 24)

## <u>SCHEDULE</u>

US Certificate of Conformity No: FM18US0021X

**11.** The marking of the equipment shall include:

## TC-Standard

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 50°C

## TC-Midi & TC Double

Class I Division 2, Groups A, B, C, D; T4 Ta = 0°C to 60°C

## **12. Description of Equipment:**

**General** - The TC- Standard; TC-MIDI & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analyzers. Sample gases contain vapor which has to be withdrawn before it reaches the gas analyzer. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-MIDI X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-MIDI+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimize wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimize wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

**Construction** – The equipment is housed in a brushed stainless-steel IP20 enclosure.

**Ratings** - TC-Standard operate at 24VDC, 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 50°C. and TC-MIDI and TC-Double Models operate at 115 VAC or 230 VAC, selectable by ordering, with an ambient temperature rating of 0°C of up to 60°C.

See Annex for Model Codes

## 13. Specific Conditions of Use:

1. When installed as Class I Division 2 equipment, the thermoelectric cooler shall be mounted within a toolsecured IP54 enclosure which is capable of accepting one or more of the Class I Division 2 wiring methods per the National Electric Code (ANSI/NFPA 70).

To verify the availability of the Approved product, please refer to www.approvalguide.com

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

SCC Accenetized CE-Pys CCPS Accredit CCN

**F** Approvals

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>

## <u>SCHEDULE</u>



US Certificate of Conformity No: FM18US0021X

## 14. Test and Assessment Procedure and Conditions:

This Certificate has been issued in accordance with FM Approvals US Certification Requirements.

## 15. Schedule Drawings

A copy of the technical documentation has been kept by FM Approvals.


## 16. Certificate History

Details of the supplements to this certificate are described below:

Date	Description
4 October 2018	Original Issue.
25 January 2021	<u>Supplement 1:</u> Report Reference: RR226270 dated 25 <sup>th</sup> January 2021. Description of the Change: Add digital interface and correct typo in model code to remove + for TC-MIDI fitted with 1 heat exchanger.
9 October 2024	Supplement 2:Report Reference: RR242035 dated 9 October 2024.Description of the Change(s):1. Addition of product variants due to changes to electronics2. FM3600 updated to latest edition (2022)3. FM3611 updated to latest edition (2021)4. FM3810 updated to latest edition (2021)5. ANSI/UL 121201:2015 updated to ANSI/UL 121201:20216. ANSI/ISA 61010-1:2012 updated to ANSI/UL 61010-1:2019

To verify the availability of the Approved product, please refer to www.approvalguide.com

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE





F 347 (Ju**l** 24)

SCHEDULE US Certificate of Conformity No: FM18US0021X



## ANNEX

## 4496 211b2d11gh0jkl0n0pTC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchanger)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35 h = Condensate drain; 00, 10 or 30 j & k = Moisture detector/Filter; 00, 01,10, or 11 I = Status Outputs; 00 or 10n = Delta T control; 00 or 10

## 4496 211b2d1fg0000l0n0p TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchanger for H2/02 applications)

## **Description of Equipment:**

 $b = Gas \ cooler \ model: 1 \ or \ 2 \\ d = Supply \ voltage; 1 \ or \ 2 \\ f, g = Heat \ exchanger; 10, 15, 10 \ or \ 15 \\ I = Status \ Outputs; \ 00 \ or \ 10 \\ n = Delta \ T \ control; \ 00 \ or \ 10 \\ p = heat \ exchanger \ optimized \ for \ high-purity \ hydrogen/oxygen; -H2 \ or \ -O2$ 

## 4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35 h = Condensate drain; 0, 2, or 4 j & k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21, 22 l = Status Outputs; 0 or 1n = Delta T control; 0 or 1

To verify the availability of the Approved product, please refer to <u>www.approvalguide.com</u>

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE





F 347 (Ju**l** 24)



SCHEDULE US Certificate of Conformity No: FM18US0021X

## 4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 22, 27, 32 or 37 h = Condensate drain; 0, 2, 4 j & k = Moisture detector/Filter; 00, 01,10, or 11 l = Signal Outputs; 0 or 1n = no value assigned.

## 4496 311 b2defghijklmno TC-MIDI X2(fitted with 1 heat exchangers)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 e = Gas path; 1 or 2 f,g = Heat exchangers; 10, 15, 20, 25, 30 or 35 h = Condensate drain; 0, 1 or 3 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 10 or 11 l,m = Signal output; 00 or 10 n,o = Delta T control; 00 or 10

## 4496 311 b2defg0000lmnop TC-MIDI X2 (fitted with 1 heat exchangers for H2/02 applications)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 e = Gas path; 1 or 2 f,g = Heat exchangers; 10, 15, 60, 65

- I,m = Signal output; 00 or 10
- n,o = Delta T control; 00 or 10
- p = heat exchanger optimized for high-purity hydrogen/oxygen; -H2 or -O2

To verify the availability of the Approved product, please refer to www.approvalguide.com

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>





SCHEDULE US Certificate of Conformity No: FM18US0021X

## 4496 312 b2d1fghijklm00 TC-MIDI + X2(fitted with 2 heat exchangers)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 f,g = Heat exchangers; 60, 65, 61, 66, 70, 75, 80 or 85 h = Condensate drain; 0, 2, or 4 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21 or 22 l,m = Signal outputs; 00 or 10 n, o = Delta T Control; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double X2

## **Description of Equipment:**

a = Gas cooler types 1 or 2 c = Voltage; 1 or 2 e,f = Heat exchangers; 10, 15, 20, 25, 30 or 35 g = Condensate drain; 0, 2, or 4 h = Sample gas pumps; 0, 1, or 2 i,j = Humidity sensor/Filter; 00, 01, 10, or 11 k,l = Signal outputs; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double+ X2

## **Description of Equipment:**

- a = Gas cooler types 1 or 2
- c = Voltage; 1 or 2
- e,f = Heat exchangers; 22, 27, 32, or 37
- g = Peristaltic pumps; 0, 2, or 4
- h = Sample gas pumps; 0, 1, or 2
- i,j = Moisture Detector/Filter; 00, 01, 10, or 11
- k, I = Status output; 00 or 10

To verify the availability of the Approved product, please refer to <u>www.approvalguide.com</u>

## THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals LLC. One Technology Way, Norwood, MA 02062 USA T: +1 (1) 781 762 4300 F: +1 (1) 781 762 9375 E-mail: <u>information@fmapprovals.com</u> <u>www.fmapprovals.com</u>



F 347 (Ju**l** 24)

. т			N CERTIFICATE	$\overline{c}$
1				$\langle X \rangle$
2	Equipment or Protective sy		-	
2	Explosive Atmospheres - D			
3	Type Examination Certificat		FM18ATEX0012X TC-Standard X2; TC-Standard+ X2; TC	
4	Equipment or protective sy (Type Reference and Name)		TC MIDI+ X2; TC-Double X2 & TC-Dou Sample Gas Cooler	
5	Name of Applicant:	F I.V.I	Bühler Technologies GmbH	
6	Address of Applicant:		Harkortstrasse 29 Ratingen, D-40880 Germany	uIJ
7	This equipment or protective this certificate and documents		any acceptable variation thereto is specified red to.	d in the schedule to
8		elating to the	equipment has been found to comply with to design and construction of equipment in Annex II to the Directive.	
	The examination and test res	ults are recor	ded in confidential report number:	
		306201	4 dated 04 <sup>th</sup> October 2018	216
9			Safety Requirements, with the exception or as been assessed by compliance with the for	
	EN 60079-0:2012	2+A11:2013,	EN 60079-7:2015+A1:2018 & EN 60079-1	5:2018
10	If the sign 'X' is placed after to conditions of use specified in		number, it indicates that the equipment is to this certificate.	s subject to specific
11	equipment or protective syste	em in accorda acturing proce	only to the design, examination and tes ance to the Directive 2014/34/EU. Further ess and supply of this equipment or protect	requirements of the
12	The marking of the equipmen	t or protective	e system shall include:	010
6	II 3 G Ex ec nC IIC T	4 Gc		<b>UI</b> )
N.	Ta = $0^{\circ}$ C to +40°C or 0°	°C to +50°C (	TC-Standard X2 & TC-Standard+ X2 Mode	els)
Va	Digitally sig DN: cn=Dai	°C to +60°C ( gned by Damien M mien Mc Ardle, o= ou=FM Approvals		
	s.com, c=IE		pproval	
	Member of the FM Global Group Date: 2020. ien Mc Ardle fication Manager, FM Approv	.02.18 18:14:19 Z vals Europe L	.td.	
	date: 18 <sup>th</sup> February 2020	-		
	-	BE REPROD	DUCED IN ITS ENTIRETY AND WITHOUT	CHANGE
FM Ap	provals Europe Ltd. One Georges Qua 3 (0) 1761 4200 E-mail: <u>atex@fmappr</u>	ay Plaza, Dublin.	Ireland. D02 E440	
F ATE	X 029 (Mar/2019)			Page 1 of 5





## to Type Examination Certificate No. FM18ATEX0012X

### 13 **Description of Equipment or Protective System:**

The TC- Standard; TC-Midi & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analysers. Sample gases contain vapour which has to be withdrawn before it reaches the gas analyser. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-Midi X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-Midi+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimise wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimise wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

## TC-Standard X2 - Sample Gas Cooler (fitted with 1 or 2 heat exchangers)

Electrical data: Umax 24VDC,115VAC or 230 VAC, 50/60 Hz, TC – Standard Models	130 W
TC – MIDI Models	290 W
TC – Double models	390 W

### 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

- b = Gas cooler model: 1 or 2
- d, = Supply voltage; 1, 2 or 4
- = Heat exchanger; 10, 15, 20, 25, 30, or 35 f,g
- = Peristaltic Pumps; 0, 1, 3 h
- = Moisture detector / Filter; 00, 01,10, or 11 j,k
  - = Status Outputs; 0 or 1
  - = Delta T control; 0 or 1

4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)


- b = Gas cooler model: 1 or 2 d
  - = Supply voltage; 1, 2 or 4
- f,g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- = Peristaltic Pumps; 0, 2, or 4 h
- j,k = Moisture detector / Filter; 00, 01, 02, 10, 11, 20, 21, 22
  - = Status Outputs: 0 or 1
- = Delta T control; 0 or 1 n

### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: atex@fmapprovals.com www.fmapprovals.com

L

n



F ATEX 029 (Mar/2019)



i,j = Moisture Detector/Filter; 00, 01, 10, or 11

### 14 Specific Conditions of Use:

 The equipment shall be mounted in an enclosure providing a minimum degree of protection of IP54 in accordance with EN 60079-15, and in a tool-secured enclosure which meets the requirements of EN 60079-0 and EN 60079-15.

### 15 Essential Health and Safety Requirements:

The relevant EHSRs that have not been addressed by the standards listed in this certificate have been identified and assessed in the confidential report identified in item 8.

### 16 Test and Assessment Procedure and Conditions:

This Type Examination Certificate is the result of testing of a sample of the product submitted, in accordance with the provisions of the relevant specific standard(s), and assessment of supporting documentation. It does not imply an assessment of the whole production.

Whilst this certificate may be used in support of a manufacturer's claim for CE Marking, FM Approvals Europe Ltd accepts no responsibility for the compliance of the equipment against all applicable Directives in all applications.

This Certificate has been issued in accordance with FM Approvals Europe Ltd's ATEX Certification Scheme.

### 17 Schedule Drawings

A list of the significant parts of the technical documentation is annexed to this certificate and a copy has been kept by FM Approvals Europe Ltd.

### 18 Certificate History

Details of the supplements to this certificate are described below:

### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> www.fmapprovals.com

F ATEX 029 (Mar/2019)




## to Type Examination Certificate No. FM18ATEX0012X

Date	Description		
15 <sup>th</sup> October 2018	Original Issue.		
18 <sup>th</sup> February 2020	Original Issue.         Supplement 1: Report Reference: RR222218 dated 17 <sup>th</sup> February 2020.         Description of the Change: <ol> <li>A correction of typographical errors in model code section and the electrical power ratings.</li> <li>Certificate transferred from FM Approvals Ltd., notified body no. 1725, to FM Approvals Europe Ltd., notified body no. 2809</li> <li>Update CDL</li> </ol>		

## FM Approvals

FM Approvals

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



Damien Mc Ardle Certification Manager, FM Approvals Europe Ltd.

Issue date: 26<sup>th</sup> January 2021

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE





## to Type Examination Certificate No. FM18ATEX0012X

### 13 **Description of Equipment or Protective System:**

The TC- Standard; TC-Midi & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analysers. Sample gases contain vapour which has to be withdrawn before it reaches the gas analyser. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-Midi X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-Midi+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimise wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimise wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

## TC-Standard X2 - Sample Gas Cooler (fitted with 1 or 2 heat exchangers)

Electrical data: Umax 24VDC,115VAC or 230 VAC, 50/60 Hz, TC - Standard Models	130 W
TC – MIDI Models	290 W
TC – Double models	390 W

## 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

- b = Gas cooler model: 1 or 2
- d, = Supply voltage; 1, 2 or 4
- f,g = Heat exchanger; 10, 15, 20, 25, 30, or 35
  - = Peristaltic Pumps; 0, 1, 3
- = Moisture detector / Filter; 00, 01,10, or 11 j,k
  - = Status Outputs; 0 or 1
  - = Delta T control; 0 or 1

4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- = Heat exchanger; 10, 15, 20, 25, 30, or 35 f,g
- = Peristaltic Pumps; 0, 2, or 4 h
- = Moisture detector / Filter; 00, 01, 02, 10, 11, 20, 21, 22 j,k Т
  - = Status Outputs; 0 or 1
- = Delta T control; 0 or 1 n


## THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE


FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: atex@fmapprovals.com www.fmapprovals.com

h

Т

n





## 14 Specific Conditions of Use:

 The equipment shall be mounted in an enclosure providing a minimum degree of protection of IP54 in accordance with EN 60079-15, and in a tool-secured enclosure which meets the requirements of EN 60079-0 and EN 60079-15.

### 15 Essential Health and Safety Requirements:

The relevant EHSRs that have not been addressed by the standards listed in this certificate have been identified and assessed in the confidential report identified in item 8.

### 16 Test and Assessment Procedure and Conditions:

This Type Examination Certificate is the result of testing of a sample of the product submitted, in accordance with the provisions of the relevant specific standard(s), and assessment of supporting documentation. It does not imply an assessment of the whole production.

Whilst this certificate may be used in support of a manufacturer's claim for CE Marking, FM Approvals Europe Ltd accepts no responsibility for the compliance of the equipment against all applicable Directives in all applications.

This Certificate has been issued in accordance with FM Approvals Europe Ltd's ATEX Certification Scheme.

### 17 Schedule Drawings

A list of the significant parts of the technical documentation is annexed to this certificate and a copy has been kept by FM Approvals Europe Ltd.

### 18 Certificate History

Details of the supplements to this certificate are described below:

### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> <u>www.fmapprovals.com</u>

F ATEX 029 (Mar/2019)



## to Type Examination Certificate No. FM18ATEX0012X

Date	Description		
15 <sup>th</sup> October 2018	Original Issue.		
18 <sup>th</sup> February 2020	Supplement 1:         Report Reference: RR222218 dated 17 <sup>th</sup> February 2020.         Description of the Change:         1. A correction of typographical errors in model code section and the electrical power ratings.         2. Certificate transferred from FM Approvals Ltd., notified body no. 1725, to FM Approvals Europe Ltd., notified body no. 2809         3. Update CDL		
26 <sup>th</sup> January 2021	Supplement 2: Report Reference: RR226270 dated 25 <sup>th</sup> January 2021. Description of the Change: Add digital interface and correct typo in model code to remove + for TC-MIDI fitted with 1 heat exchanger.		

# FM Approvals

FM Approvals

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



## **1. TYPE EXAMINATION CERTIFICATE**

- 2. Equipment or Protective systems intended for use in Potentially Explosive Atmospheres - Directive 2014/34/EU
- 3. Type Examination Certificate No:
- 4. Equipment or protective system: (Type Reference and Name)

5. Name of Applicant:

6. Address of Applicant

FM18ATEX0012X

TC-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC-MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas Cooler

Bühler Technologies GmbH

Harkortstraße 29, Ratingen D-40880, Germany

- 7. This equipment or protective system and any acceptable variation thereto is specified in the schedule to this certificate and documents therein referred to.
- 8. FM Approvals Europe Ltd, certifies that this component has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment intended for use in potentially explosive atmospheres given in Annex II to the Directive.

The examination and test results are recorded in confidential report number:

3062014 dated 4<sup>th</sup> October 2018

9. Compliance with the Essential Health and Safety Requirements, with the exception of those identified in item 15 of the schedule to this certificate, has been assessed by compliance with the following documents:

EN IEC 60079-0:2018, EN 60079-7:2015+A1:2018, EN IEC 60079-15:2019

- 10. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 11. This Type Examination certificate relates only to the design, examination and tests of the specified equipment or protective system in accordance to the Directive 2014/34/EU. Further requirements of the Directive apply to the manufacturing process and supply of this equipment or protective system. These are not covered by this certificate.

Certificate issued by:				
Certification Manager, FM Approvals Europe Ltd.	Date 10 October 2024			
THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. DO2 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> F ATEX 029 (Jul/2024)				



to Type Examination Certificate No. FM18ATEX0012X

## 12. The marking of the equipment or protective system shall include:



 $\frac{\text{TC-Standard}}{\text{II 3 G Ex ec nC IIC T4 Gc}}$ Ta = 0°C to +40°C or 0°C to +50°C

 $\frac{\text{TC-MIDI \& TC Double}}{\text{II 3 G Ex ec nC IIC T4 Gc}}$  $\text{Ta = 0^{\circ}C \text{ to } +40^{\circ}C \text{ or } 0^{\circ}C \text{ to } +60^{\circ}C$ 

## 13. Description of Equipment or Protective System:

The TC- Standard; TC-MIDI & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analyzers. Sample gases contain vapor which has to be withdrawn before it reaches the gas analyzer. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-MIDI X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-MIDI+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimize wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimize wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

TC-Standard X2 - Sample Gas Cooler (fitted with 1 or 2 heat exchangers)

Electrical data: Umax 24VDC,115VAC or 230 VAC, 50/60 Hz

- TC Standard Models 130 W
- TC MIDI Models 290 W
- TC Double models 390 W

See Annex for Model Codes

## 14. Specific Conditions of Use:

1. The equipment shall be installed within a tool-secured enclosure providing a minimum degree of protection of IP54 and meeting the requirements of EN 60079-0 or certified as Ex e and in

## THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



to Type Examination Certificate No. FM18ATEX0012X

compliance with the enclosure, mounting, spacing and segregation requirements of the ultimate application.

## 15. Essential Health and Safety Requirements:

The relevant EHSRs that have not been addressed by the standards listed in this certificate have been identified and assessed in the confidential report identified in item 8.

## 16. Test and Assessment Procedure and Conditions:

This Type Examination Certificate is the result of testing of a sample of the product submitted, in accordance with the provisions of the relevant specific standard(s), and assessment of supporting documentation. It does not imply an assessment of the whole production.

Whilst this certificate may be used in support of a manufacturer's claim for CE Marking, FM Approvals Europe Ltd accepts no responsibility for the compliance of the equipment against all applicable Directives in all applications.

This Certificate has been issued in accordance with FM Approvals Europe Ltd's ATEX Certification Scheme.

## 17. Schedule Drawings

A list of the significant parts of the technical documentation is annexed to this certificate and a copy has been kept by FM Approvals Europe Ltd.

## 18. Certificate History

Details of the supplements to this certificate are described below:

Date	Description
15 October 2018	Original Issue.
18 February 2020	<ul> <li>Supplement 1: Report Reference: RR222218 dated 17<sup>th</sup> February 2020.</li> <li>Description of the Change: <ol> <li>A correction of typographical errors in model code section and the electrical power ratings.</li> <li>Certificate transferred from FM Approvals Ltd., notified body no. 1725, to FM Approvals Europe Ltd., notified body no. 2809</li> <li>Update CDL</li> </ol></li></ul>
26 January 2021	Supplement 2: Report Reference: RR226270 dated 25 <sup>th</sup> January 2021. Description of the Change: Add digital interface and correct typo in model code to remove + for TC-MIDI fitted with 1 heat exchanger.
10 October 2024	Supplement 3:Report Reference: RR242035 dated 9 October 2024.Description of the Change(s):1. Addition of product variants due to changes to electronics2. EN 60079-0:2012+A11:2013 updated to EN IEC 60079-0:2018

## THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



to Type Examination Certificate No. FM18ATEX0012X

## ANNEX

## 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

## **Description of Equipment:**

 $b = Gas \ cooler \ model: 1 \ or \ 2$   $d = Supply \ voltage; 1, 2 \ or \ 4$   $f \& g = Heat \ exchanger; 10, 15, 20, 25, 30, or \ 35$   $h = Condensate \ drain; 00, 10 \ or \ 30$   $j \& k = Moisture \ detector/Filter; 00, 01, 10, or \ 11$   $l = Status \ Outputs; 00 \ or \ 10$  $n = Delta \ T \ control; 00 \ or \ 10$ 

## 4496 211b2d1fg0000l0n0p TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchanger for H2/O2 applications)

## **Description of Equipment:**

 $b = Gas \ cooler \ model: 1 \ or \ 2 \\ d = Supply \ voltage; 1 \ or \ 2 \\ f, g = Heat \ exchanger; 10, 15, 10 \ or \ 15 \\ l = Status \ Outputs; 00 \ or \ 10 \\ n = Delta \ T \ control; 00 \ or \ 10 \\ p = heat \ exchanger \ optimized \ for \ high-purity \ hydrogen/oxygen; -H2 \ or \ -O2$ 

## 4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35 h = Condensate drain; 0, 2, or 4 j & k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21, 22

- I = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



to Type Examination Certificate No. FM18ATEX0012X

## 4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 22, 27, 32 or 37 h = Condensate drain; 0, 2, 4 j & k = Moisture detector/Filter; 00, 01,10, or 11 l = Signal Outputs; 0 or 1 n = no value assigned.

## 4496 311 b2defghijklmno TC-MIDI X2(fitted with 1 heat exchangers)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 e = Gas path; 1 or 2 f,g = Heat exchangers; 10, 15, 20, 25, 30 or 35 h = Condensate drain; 0, 1 or 3 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 10 or 11 l,m = Signal output; 00 or 10n,o = Delta T control; 00 or 10

## 4496 311 b2defg0000lmnop TC-MIDI X2 (fitted with 1 heat exchangers for H2/02 applications)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 e = Gas path; 1 or 2 f,g = Heat exchangers; 10, 15, 60, 65 l,m = Signal output; 00 or 10 n,o = Delta T control; 00 or 10p = heat exchanger optimized for high-purity hydrogen/oxygen; -H2 or -O2

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> <u>www.fmapprovals.com</u> **F** Approvals

<u>SCHEDULE</u>



to Type Examination Certificate No. FM18ATEX0012X

## 4496 312 b2d1fghijklm00 TC-MIDI + X2(fitted with 2 heat exchangers)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 f,g = Heat exchangers; 60, 65, 61, 66, 70, 75, 80 or 85 h = Condensate drain; 0, 2, or 4 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21 or 22 l,m = Signal outputs; 00 or 10n, o = Delta T Control; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double X2

## **Description of Equipment:**

a = Gas cooler types 1 or 2 c = Voltage; 1 or 2 e,f = Heat exchangers; 10, 15, 20, 25, 30 or 35 g = Condensate drain; 0, 2, or 4 h = Sample gas pumps; 0, 1, or 2 i,j = Humidity sensor/Filter; 00, 01, 10, or 11

k,l = Signal outputs; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double+ X2

## **Description of Equipment:**

a = Gas cooler types 1 or 2 c = Voltage; 1 or 2 e,f = Heat exchangers; 22, 27, 32, or 37 g = Peristaltic pumps; 0, 2, or 4 h = Sample gas pumps; 0, 1, or 2 i,j = Moisture Detector/Filter; 00, 01, 10, or 11 k,l = Status output; 00 or 10

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



## **1. TYPE EXAMINATION CERTIFICATE**

- 2. Equipment or Protective systems intended for use in Potentially Explosive Atmospheres - Directive 2014/34/EU
- 3. Type Examination Certificate No:
- 4. Equipment or protective system: (Type Reference and Name)
- 5. Name of Applicant:
- 6. Address of Applicant

## FM18ATEX0012X

TC-Standard X2; TC-Standard+ X2; TC-MIDI X2; TC-MIDI+ X2; TC-Double X2 & TC-Double+ X2 Sample Gas Cooler

Bühler Technologies GmbH

Harkortstraße 29, Ratingen D-40880, Germany

- 7. This equipment or protective system and any acceptable variation thereto is specified in the schedule to this certificate and documents therein referred to.
- 8. FM Approvals Europe Ltd, certifies that this component has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment intended for use in potentially explosive atmospheres given in Annex II to the Directive.

The examination and test results are recorded in confidential report number:

## 3062014 dated 4<sup>th</sup> October 2018

9. Compliance with the Essential Health and Safety Requirements, with the exception of those identified in item 15 of the schedule to this certificate, has been assessed by compliance with the following documents:

EN IEC 60079-0:2018, EN 60079-7:2015+A1:2018, EN IEC 60079-15:2019

- 10. If the sign 'X' is placed after the certificate number, it indicates that the equipment is subject to specific conditions of use specified in the schedule to this certificate.
- 11. This Type Examination certificate relates only to the design, examination and tests of the specified equipment or protective system in accordance to the Directive 2014/34/EU. Further requirements of the Directive apply to the manufacturing process and supply of this equipment or protective system. These are not covered by this certificate.

Certificate issued by:

6 December 2024

Certification Manager, FM Approvals Europe Ltd.

Date

## THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> <u>www.fmapprovals.com</u>

F ATEX 029 (Ju**l**/2024)

Page 1 of 7

to Type Examination Certificate No. FM18ATEX0012X

## 12. The marking of the equipment or protective system shall include:



 $\frac{\text{TC-Standard}}{\text{II 3 G Ex ec nC IIC T4 Gc}}$ Ta = 0°C to +40°C or 0°C to +50°C

TC-MIDI & TC DoubleII 3 G Ex ec nC IIC T4 GcTa = 0°C to +40°C or 0°C to +60°C

## 13. Description of Equipment or Protective System:

The TC- Standard; TC-MIDI & TC-Double sample gas chillers are intended to cool and dry the sample gas before going into the gas analyzers. Sample gases contain vapor which has to be withdrawn before it reaches the gas analyzer. The Gas flows through a heat exchanger (impinger) inserted into a cooling block. The latter then is cooled to a pre-set temperature (5°C mostly).

Depending on the required cooling capacity the size of the heat exchanger and therefore chiller is chosen and depending on the kind of gas to be cooled different heat exchanger materials are provided (stainless steel, glass or PVDF).

A gas cooler (chiller) might be prepared for more than one heat exchanger. The cooling block is cooled by different combinations of Peltier-elements. The temperature is sensed by an RTD.

The TC-Standard X2 / TC-MIDI X2 series of sample coolers are designed specifically for high cooling capacities and high ambient temperatures.

The TC-Standard+ X2 / TC-MIDI+ X2 series are designed specifically for the requirements in automated measuring systems (AMS) according to EN 15267-3. The series connection of the heat exchangers will cool in two cycles to minimize wash out effects.

The TC-Double X2 series are designed specifically for high cooling capacities, high ambient temperatures and to cool in two cycles to minimize wash out effects.

The TC-Double+ X2 incorporates two cooling blocks that can be set do different temperatures.

TC-Standard X2 - Sample Gas Cooler (fitted with 1 or 2 heat exchangers)

Electrical data: Umax 24VDC,115VAC or 230 VAC, 50/60 Hz

- TC Standard Models 130 W
- TC MIDI Models 290 W
- TC Double models 390 W

See Annex for Model Codes

## 14. Specific Conditions of Use:

1. The equipment shall be installed within a tool-secured enclosure providing a minimum degree of protection of IP54 and meeting the requirements of EN 60079-0 or certified as Ex e and in

### THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> <u>www.fmapprovals.com</u> **F** Approvals



### to Type Examination Certificate No. FM18ATEX0012X

compliance with the enclosure, mounting, spacing and segregation requirements of the ultimate application.

### 15. Essential Health and Safety Requirements:

The relevant EHSRs that have not been addressed by the standards listed in this certificate have been identified and assessed in the confidential report identified in item 8.

## 16. Test and Assessment Procedure and Conditions:

This Type Examination Certificate is the result of testing of a sample of the product submitted, in accordance with the provisions of the relevant specific standard(s), and assessment of supporting documentation. It does not imply an assessment of the whole production.

Whilst this certificate may be used in support of a manufacturer's claim for CE Marking, FM Approvals Europe Ltd accepts no responsibility for the compliance of the equipment against all applicable Directives in all applications.

This Certificate has been issued in accordance with FM Approvals Europe Ltd's ATEX Certification Scheme.

## 17. Schedule Drawings

A list of the significant parts of the technical documentation is annexed to this certificate and a copy has been kept by FM Approvals Europe Ltd.

## **18. Certificate History**

Details of the supplements to this certificate are described below:

Date	Description
15 October 2018	Original Issue.
18 February 2020	<ul> <li>Supplement 1: Report Reference: RR222218 dated 17<sup>th</sup> February 2020. Description of the Change: <ol> <li>A correction of typographical errors in model code section and the electrical power ratings.</li> <li>Certificate transferred from FM Approvals Ltd., notified body no. 1725, to FM Approvals Europe Ltd., notified body no. 2809</li> <li>Update CDL</li> </ol></li></ul>
26 January 2021	Supplement 2: Report Reference: RR226270 dated 25 <sup>th</sup> January 2021. Description of the Change: Add digital interface and correct typo in model code to remove + for TC-MIDI fitted with 1 heat exchanger.

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE



SCHEDULE to Type Examination Certificate No. FM18ATEX0012X

Date	Description
10 October 2024	Supplement 3: Report Reference: RR242035 dated 10 October 2024. Description of the Change(s): 1. Addition of product variants due to changes to electronics 2. EN 60079-0:2012+A11:2013 updated to EN IEC 60079-0:2018
6 December 2024	Supplement 4: Report Reference: RR243713 dated 5 December 2024. Description of the Change(s): Document Updates

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

SCHEDULE to Type Examination Certificate No. FM18ATEX0012X

## ANNEX

## 4496 211b2d1fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchangers)

## **Description of Equipment:**

 $b = Gas \ cooler \ model: 1 \ or \ 2$   $d = Supply \ voltage; 1, 2 \ or \ 4$   $f \& g = Heat \ exchanger; 10, 15, 20, 25, 30, or \ 35$   $h = Condensate \ drain; 00, 10 \ or \ 30$   $j \& k = Moisture \ detector/Filter; 00, 01, 10, or \ 11$   $I = Status \ Outputs; 00 \ or \ 10$  $n = Delta \ T \ control; 00 \ or \ 10$ 

## 4496 211b2d1fg0000l0n0p TC-Standard X2 - Sample Gas Cooler (fitted with 1 heat exchanger for H2/02 applications)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1 or 2 f, g = Heat exchanger; 10, 15, 10 or 15 I = Status Outputs; 00 or 10 n = Delta T control; 00 or 10 p = heat exchanger optimized for high-purity hydrogen/oxygen; -H2 or -O2

## 4496 212b2d2fgh0jkl0n0 TC-Standard X2 - Sample Gas Cooler (fitted with 2 heat exchangers)

## **Description of Equipment:**

- b = Gas cooler model: 1 or 2
- d = Supply voltage; 1, 2 or 4
- f & g = Heat exchanger; 10, 15, 20, 25, 30, or 35
- h = Condensate drain; 0, 2, or 4
- j & k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21, 22
- I = Status Outputs; 0 or 1
- n = Delta T control; 0 or 1

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. DO2 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> <u>www.fmapprovals.com</u> **F** Approvals



SCHEDULE to Type Examination Certificate No. FM18ATEX0012X

## 4496 212b2d2fgh0jkl0n0 TC-Standard+ X2 - Sample Gas Cooler (with 2 heat exchangers in series)

## **Description of Equipment:**

b = Gas cooler model: 1 or 2 d = Supply voltage; 1, 2 or 4 f & g = Heat exchanger; 22, 27, 32 or 37 h = Condensate drain; 0, 2, 4 j & k = Moisture detector/Filter; 00, 01,10, or 11 l = Signal Outputs; 0 or 1 n = no value assigned.

## 4496 311 b2defghijkImno TC-MIDI X2(fitted with 1 heat exchangers)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 e = Gas path; 1 or 2 f,g = Heat exchangers; 10, 15, 20, 25, 30 or 35 h = Condensate drain; 0, 1 or 3 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 10 or 11 l,m = Signal output; 00 or 10 n,o = Delta T control; 00 or 10

## 4496 311 b2defg0000lmnop TC-MIDI X2 (fitted with 1 heat exchangers for H2/02 applications)

## **Description of Equipment:**

 $b = Gas \ cooler \ types 1 \ or \ 2 \\ d = Supply \ Voltage; \ 1 \ or \ 2 \\ e = Gas \ path; \ 1 \ or \ 2 \\ f,g = Heat \ exchangers; \ 10, \ 15, \ 60, \ 65 \\ l,m = Signal \ output; \ 00 \ or \ 10 \\ n,o = Delta \ T \ control; \ 00 \ or \ 10 \\ p = heat \ exchanger \ optimized \ for \ high-purity \ hydrogen/oxygen; \ -H2 \ or \ -O2$ 

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

to Type Examination Certificate No. FM18ATEX0012X

## 4496 312 b2d1fghijklm00 TC-MIDI + X2(fitted with 2 heat exchangers)

## **Description of Equipment:**

b = Gas cooler types 1 or 2 d = Supply Voltage; 1 or 2 f,g = Heat exchangers; 60, 65, 61, 66, 70, 75, 80 or 85 h = Condensate drain; 0, 2, or 4 i = Sample gas pumps; 0, 1, 2, 6, or 7 j,k = Moisture detector/Filter; 00, 01, 02, 10, 11, 20, 21 or 22 l,m = Signal outputs; 00 or 10n, o = Delta T Control; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double X2

### **Description of Equipment:**

a = Gas cooler types 1 or 2 c = Voltage; 1 or 2 e,f = Heat exchangers; 10, 15, 20, 25, 30 or 35 g = Condensate drain; 0, 2, or 4 h = Sample gas pumps; 0, 1, or 2

- i, j = Humidity sensor/Filter; 00, 01, 10, or 11
- k,I = Signal outputs; 00 or 10

## 4496 611a2c1efghijkl000 TC-Double+ X2

## **Description of Equipment:**

- a = Gas cooler types 1 or 2
- c = Voltage; 1 or 2
- e,f = Heat exchangers; 22, 27, 32, or 37
- g = Peristaltic pumps; 0, 2, or 4
- h = Sample gas pumps; 0, 1, or 2
- i,j = Moisture Detector/Filter; 00, 01, 10, or 11
- k,l = Status output; 00 or 10

THIS CERTIFICATE MAY ONLY BE REPRODUCED IN ITS ENTIRETY AND WITHOUT CHANGE

FM Approvals Europe Ltd. One Georges Quay Plaza, Dublin. Ireland. D02 E440 T: +353 (0) 1761 4200 E-mail: <u>atex@fmapprovals.com</u> <u>www.fmapprovals.com</u> **FM** Approvals

## RMA-Formular und Erklärung über Dekontaminierung **RMA-Form and explanation for decontamination**



## RMA-Nr./ RMA-No.

Die RMA-Nr. bekommen Sie von Ihrem Ansprechpartner im Vertrieb oder Service. Bei Rücksendung eines Altgeräts zur Entsorgung tragen Sie bitte in das Feld der RMA-Nr. "WEEE" ein./ You may obtain the RMA number from your sales or service representative. When returning an old appliance for disposal, please enter "WEEE" in the RMA number box.

Zu diesem Rücksendeschein gehört eine Dekontaminierungserklärung. Die gesetzlichen Vorschriften schreiben vor, dass Sie uns diese Dekontaminierungserklärung ausgefüllt und unterschrieben zurücksenden müssen. Bitte füllen Sie auch diese im Sinne der Gesundheit unserer Mitarbeiter vollständig aus./ This return form includes a decontamination statement. The law requires you to submit this completed and signed decontamination statement to us. Please complete the entire form, also in the interest of our employee health.

Firma/ Company		Ansprechpartner/ Person in charge	
Firma/ Company		Name/ Name	
Straße/ Street		Abt./ Dept.	
PLZ, Ort/ Zip, City		Tel./ Phone	
Land/ Country		E-Mail	
Gerät/ Device		Serien-Nr./ Serial No. Artikel-Nr./ Item No.	
Auftragsnr./ Order No. Grund der Rücksendung/ Reason for return		bitte spezifizieren/ please specify	
Kalibrierung/ Calibration	Modifikation/ Modification		


- Reklamation/ Claim
  - Reparatur/ Repair
- Elektroaltgerät/ Waste Electrical & Electronic Equipment (WEEE)
- andere/ other

## Ist das Gerät möglicherweise kontaminiert?/ Could the equipment be contaminated?

Nein, da das Gerät nicht mit gesundheitsgefährdenden Stoffen betrieben wurde./ No, because the device was not operated with hazardous substances.

Nein, da das Gerät ordnungsgemäß gereinigt und dekontaminiert wurde./ No, because the device has been properly cleaned and decontaminated.

Ja, kontaminiert mit:/ Yes, contaminated with:



### Bitte Sicherheitsdatenblatt beilegen!/ Please enclose safety data sheet!

Das Gerät wurde gespült mit:/ The equipment was purged with:

Diese Erklärung wurde korrekt und vollständig ausgefüllt und von einer dazu befugten Person unterschrieben. Der Versand der (dekontaminierten) Geräte und Komponenten erfolgt gemäß den gesetzlichen Bestimmungen.

Falls die Ware nicht gereinigt, also kontaminiert bei uns eintrifft, muss die Firma Bühler sich vorbehalten, diese durch einen externen Dienstleister reinigen zu lassen und Ihnen dies in Rechnung zu stellen.

Firmenstempel/ Company Sign

This declaration has been filled out correctly and completely, and signed by an authorized person. The dispatch of the (decontaminated) devices and components takes place according to the legal regulations.

Should the goods not arrive clean, but contaminated, Bühler reserves the right, to comission an external service provider to clean the goods and invoice it to vour account.

Datum/ Date

rechtsverbindliche Unterschrift/ Legally binding signature

Bühler Technologies GmbH, Harkortstr. 29, D-40880 Ratingen Tel. +49 (0) 21 02 / 49 89-0, Fax: +49 (0) 21 02 / 49 89-20 E-Mail: service@buehler-technologies.com Internet: www.buehler-technologies.com



## Vermeiden von Veränderung und Beschädigung der einzusendenden Baugruppe

Die Analyse defekter Baugruppen ist ein wesentlicher Bestandteil der Qualitätssicherung der Firma Bühler Technologies GmbH. Um eine aussagekräftige Analyse zu gewährleisten muss die Ware möglichst unverändert untersucht werden. Es dürfen keine Veränderungen oder weitere Beschädigungen auftreten, die Ursachen verdecken oder eine Analyse unmöglich machen.

## Umgang mit elektrostatisch sensiblen Baugruppen

Bei elektronischen Baugruppen kann es sich um elektrostatisch sensible Baugruppen handeln. Es ist darauf zu achten, diese Baugruppen ESD-gerecht zu behandeln. Nach Möglichkeit sollten die Baugruppen an einem ESD-gerechten Arbeitsplatz getauscht werden. Ist dies nicht möglich sollten ESD-gerechte Maßnahmen beim Austausch getroffen werden. Der Transport darf nur in ESD-gerechten Behältnissen durchgeführt werden. Die Verpackung der Baugruppen muss ESD-konform sein. Verwenden Sie nach Möglichkeit die Verpackung des Ersatzteils oder wählen Sie selber eine ESD-gerechte Verpackung.

## Einbau von Ersatzteilen

Beachten Sie beim Einbau des Ersatzteils die gleichen Vorgaben wie oben beschrieben. Achten Sie auf die ordnungsgemäße Montage des Bauteils und aller Komponenten. Versetzen Sie vor der Inbetriebnahme die Verkabelung wieder in den ursprünglichen Zustand. Fragen Sie im Zweifel beim Hersteller nach weiteren Informationen.

## Einsenden von Elektroaltgeräten zur Entsorgung

Wollen Sie ein von Bühler Technologies GmbH stammendes Elektroprodukt zur fachgerechten Entsorgung einsenden, dann tragen Sie bitte in das Feld der RMA-Nr. "WEEE" ein. Legen Sie dem Altgerät die vollständig ausgefüllte Dekontaminierungserklärung für den Transport von außen sichtbar bei. Weitere Informationen zur Entsorgung von Elektroaltgeräten finden Sie auf der Webseite unseres Unternehmens.

## Avoiding alterations and damage to the components to be returned

Analysing defective assemblies is an essential part of quality assurance at Bühler Technologies GmbH. To ensure conclusive analysis the goods must be inspected unaltered, if possible. Modifications or other damages which may hide the cause or render it impossible to analyse are prohibited.

## Handling electrostatically conductive components

Electronic assemblies may be sensitive to static electricity. Be sure to handle these assemblies in an ESD-safe manner. Where possible, the assembles should be replaced in an ESD-safe location. If unable to do so, take ESD-safe precautions when replacing these. Must be transported in ESD-safe containers. The packaging of the assemblies must be ESD-safe. If possible, use the packaging of the spare part or use ESD-safe packaging.

## Fitting of spare parts

Observe the above specifications when installing the spare part. Ensure the part and all components are properly installed. Return the cables to the original state before putting into service. When in doubt, contact the manufacturer for additional information.

## Returning old electrical appliances for disposal

If you wish to return an electrical product from Bühler Technologies GmbH for proper disposal, please enter "WEEE" in the RMA number box. Please attach the fully completed decontamination declaration form for transport to the old appliance so that it is visible from the outside. You can find more information on the disposal of old electrical appliances on our company's website.

