

Sample gas probe GAS 222.31 Atex

In many applications gas analysis is the key for safe and efficient control of process flows, environmental protection and quality assurance. In extractive gas analysis the location of the gas sampling point is crucial for the reproducibility and accuracy of the analysis results.

The specific filter capacity, corrosion resistance and functional equipment requirements for the probe arise from the composition of the sample gas.

However, operating costs are also an important criterion in the selection, as the sampling points are frequently located at hard to access points in the system. Effective particle filter backwashing options and low maintenance characterise the extensive GAS probe series.

Versions with Atex approval

Heated probe with shut-off valve, upstream filter and weather hood

The probe body and the area around the screw connection for the heated sample gas line are completely isolated

Heater self-regulating to approx. 90 °C


For dust loads up to 200 g/m³

This probe is designed for use in explosive areas (Zone 21, 22 and extracting from Zone 20)



GAS 222.31 Atex

Flow chart



Technical Data

Gas Probe Technical Data

Ambient temperature without accessories:	-20 to +50 °C				
Ambient temperature for accessories:	Component	Ambient temperature range			
	Compressed air valve:	-10 °C < T _{amb} < +60 °C			
	Limit switch:	-20 °C < T _{amb} < +60 °C			
	Solenoid valve for pneumatic drive:	-10 °C < T _{amb} < +60 °C			
Permissible gas inlet temperatures:	Outer zone temperature class	Permissible gas inlet temperature			
	Т3	135 °C			
	T4	130 °C			
Self-regulating heater:	+90 °C				
Electrical data:	Probe:	External circuit breaker type C:			
	230 V, 2.0 A, 50/60 Hz	230 V, 3 A, 50/60 Hz			
	115 V, 3.8 A, 50/60 Hz	115 V, 4 A, 50/60 Hz			
Max. operating pressure	6 bar				
Max. flow rate:	1000 L/h				
Material:	1.4571; ball valve 1.4408				
Parts in contact with media:	Seals: Graphite/1.4404 and see filter				
Marks*:	ATEX: 🐼 1GD / 2 GD T4 T130 °C				

* Please note, using special accessories may limit the approved applications of the probes.

Ordering instructions

The item number is a code for the configuration of your unit. Please use the following model key:

										Flange
										DIN DN65 PN6
										Explosive outdoor areas
	4									Zone 21
	5									Zone 22
										Explosive indoor areas
		3								Zone 20
		4								Zone 21
		5								Zone 22
										Ex temperature classes
			4							Τ4
										Probe voltage
				1						115 V
				2						230 V
										Calibrating gas connection
					0					No calibrating gas connection
					1					6 mm
					2					6 mm + check valve
					3					1/4"
					4					1/4" + check valve
										Blowback with air reservoir ²⁾
										Compressed air valve / valve voltage information
							0			Manual
							1			115 V (labelled "mb")
							2			230 V (labelled "mb")
							3			24 V (labelled "mb")
							9			None (if no blowback requested)
										Pneumatic drive for ball valve
							0			Manual
							1			Monostable pressure-free open
							2			Monostable pressure-free closed
										Limit switch for pneumatic drive
								1		Yes (labelled "db")
								9		No
										Control valve for pneumatic drive
										3/2-way valve
									9	No control valve

¹⁾ Please note, using certain accessories may limit gas probe use in Ex areas! Observe the respective operating manuals, accessory compatibility charts, and data sheets to ensure proper technical product design!

²⁾ For flammable sample gas, always use inert gas for blowback. Probe blowback prohibited when using explosive gases!

Options

The base unit becomes functional by adding accessories suitable for the application. Please refer to accessory data sheet no. 461099 for information.

Please also refer to data sheet no. 461000 "GAS 222 Gas Probes" for a general description.



Dimensions

